



**NEXCOM International Co., Ltd.**

**Intelligent Platform & Services Business Unit**

**AI Edge Computer**

**AIEdge-X<sup>®</sup>500**

**User Manual**

# CONTENTS

## Preface

|  |      |
|--|------|
| Copyright .....                          | iv   |
| Disclaimer .....                         | iv   |
| Acknowledgements .....                   | iv   |
| Regulatory Compliance Statements .....   | iv   |
| Declaration of Conformity .....          | iv   |
| RoHS Compliance .....                    | v    |
| Warranty and RMA .....                   | vi   |
| Safety Information .....                 | viii |
| Installation Recommendations .....       | viii |
| Safety Precautions .....                 | ix   |
| Technical Support and Assistance .....   | x    |
| Conventions Used in this Manual .....    | x    |
| Global Service Contact Information ..... | xi   |
| Package Contents .....                   | xiii |
| Ordering Information .....               | xiv  |

## Chapter 1: Product Introduction

|                               |   |
|-------------------------------|---|
| AIEdge-X®500 .....            | 1 |
| Overview .....                | 1 |
| Key Features .....            | 1 |
| Hardware Specifications ..... | 2 |
| Physical Features .....       | 4 |
| Mechanical Dimensions .....   | 5 |

## Chapter 2: Jumpers and Connectors

|  |    |
|--|----|
| Before You Begin .....   | 6  |
| Precautions .....  | 6  |
| Jumper Settings .....  | 7  |
| Locations of the Jumpers and Connectors for AIEdge-X®500 ..... | 8  |
| Top View .....   | 8  |
| Bottom View .....  | 9  |
| Jumpers .....  | 10 |
| AT/ATX Mode Select .....                                       | 10 |
| Internal Connectors .....                                      | 11 |
| SPI Connector .....  | 11 |
| Front Panel Connector .....                                    | 11 |
| DC IN Connector .....  | 12 |
| 12V Power Connector .....                                      | 12 |
| CPU Fan Connector .....  | 13 |
| System Fan Connector .....                                     | 13 |
| GPIO Connector .....   | 14 |
| USB Connector .....  | 14 |
| USB Connector .....  | 15 |
| USB Connector .....  | 15 |
| COM Port Connector .....                                       | 16 |
| COM Port Connector .....                                       | 16 |
| COM Port Connector .....                                       | 17 |
| COM Port Connector .....                                       | 17 |
| SATA Connector .....   | 18 |
| SATA Connector .....   | 18 |



|                             |    |
|-----------------------------|----|
| SATA Connector.....         | 19 |
| SATA Connector.....         | 19 |
| SATA Power Connector .....  | 20 |
| SATA Power Connector .....  | 20 |
| 80 Port Connector .....     | 21 |
| M.2 Connector (M-Key) ..... | 22 |

## Chapter 3: System Setup

|   |    |
|---|----|
| Removing the Two Top Covers from the Chassis..... | 23 |
| Installing a Memory Module.....                   | 25 |
| Installing a CPU.....                             | 27 |
| Installing an Add-on Card .....                   | 31 |
| Installing a 2.5" Storage Drive (External) .....  | 33 |

## Chapter 4: BIOS Setup

|                                 |    |
|---------------------------------|----|
| About BIOS Setup .....          | 34 |
| When to Configure the BIOS..... | 34 |
| Default Configuration .....     | 35 |
| Entering Setup .....            | 35 |
| Legends.....                    | 35 |
| BIOS Setup Utility.....         | 37 |
| Main .....                      | 37 |
| Advanced .....                  | 38 |
| Chipset.....                    | 48 |
| Security .....                  | 50 |
| Boot.....                       | 50 |
| Save & Exit .....               | 51 |

# PREFACE

## Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from NEXCOM International Co., Ltd.

## Disclaimer

The information in this document is subject to change without prior notice and does not represent commitment from NEXCOM International Co., Ltd. However, users may update their knowledge of any product in use by constantly checking its manual posted on our website: <http://www.nexcom.com>. NEXCOM shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of any product, nor for any infringements upon the rights of third parties, which may result from such use. Any implied warranties of merchantability or fitness for any particular purpose is also disclaimed.

## Acknowledgements

AIEdge-X®500 is a trademark of NEXCOM International Co., Ltd. All other product names mentioned herein are registered trademarks of their respective owners.

## Regulatory Compliance Statements

This section provides the FCC compliance statement for Class A devices and describes how to keep the system CE compliant.

## Declaration of Conformity

### FCC

This equipment has been tested and verified to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area (domestic environment) is likely to cause harmful interference, in which case the user will be required to correct the interference (take adequate measures) at their own expense.

### CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

## RoHS Compliance



### **NEXCOM RoHS Environmental Policy and Status Update**

NEXCOM is a global citizen for building the digital infrastructure. We are committed to providing green products and services, which are compliant with European Union RoHS (Restriction on Use of Hazardous Substance in Electronic Equipment) directive 2011/65/EU, to be your trusted green partner and to protect our environment.

RoHS restricts the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium (Cr6+) < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm, and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm.

In order to meet the RoHS compliant directives, NEXCOM has established an engineering and manufacturing task force to implement the introduction of green products. The task force will ensure that we follow the standard NEXCOM development procedure and that all the new RoHS components and new manufacturing processes maintain the highest industry quality levels for which NEXCOM are renowned.

The model selection criteria will be based on market demand. Vendors and suppliers will ensure that all designed components will be RoHS compliant.

### **How to recognize NEXCOM RoHS Products?**

For existing products where there are non-RoHS and RoHS versions, the suffix “(LF)” will be added to the compliant product name.

All new product models launched after January 2013 will be RoHS compliant. They will use the usual NEXCOM naming convention.

## Warranty and RMA

### NEXCOM Warranty Period

NEXCOM manufactures products that are new or equivalent to new in accordance with industry standard. NEXCOM warrants that products will be free from defect in material and workmanship for 2 years, beginning on the date of invoice by NEXCOM.

### NEXCOM Return Merchandise Authorization (RMA)

- Customers shall enclose the “NEXCOM RMA Service Form” with the returned packages.
- Customers must collect all the information about the problems encountered and note anything abnormal or, print out any on-screen messages, and describe the problems on the “NEXCOM RMA Service Form” for the RMA number apply process.
- Customers can send back the faulty products with or without accessories (manuals, cable, etc.) and any components from the card, such as CPU and RAM. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, NEXCOM is not responsible for the devices/parts.
- Customers are responsible for the safe packaging of defective products, making sure it is durable enough to be resistant against further damage and deterioration during transportation. In case of damages occurred during transportation, the repair is treated as “Out of Warranty.”
- Any products returned by NEXCOM to other locations besides the customers’ site will bear an extra charge and will be billed to the customer.

### Repair Service Charges for Out-of-Warranty Products

NEXCOM will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

#### System Level

- Component fee: NEXCOM will only charge for main components such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistor, capacitor.
- Items will be replaced with NEXCOM products if the original one cannot be repaired. Ex: motherboard, power supply, etc.
- Replace with 3rd party products if needed.
- If RMA goods can not be repaired, NEXCOM will return it to the customer without any charge.

#### Board Level

- Component fee: NEXCOM will only charge for main components, such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistors, capacitors.
- If RMA goods can not be repaired, NEXCOM will return it to the customer without any charge.

## Warnings

Read and adhere to all warnings, cautions, and notices in this guide and the documentation supplied with the chassis, power supply, and accessory modules. If the instructions for the chassis and power supply are inconsistent with these instructions or the instructions for accessory modules, contact the supplier to find out how you can ensure that your computer meets safety and regulatory requirements.

## Cautions

Electrostatic discharge (ESD) can damage system components. Do the described procedures only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.

## Safety Information

Before installing and using the device, note the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Follow all warnings and cautions in this manual.
- When replacing parts, ensure that your service technician uses parts specified by the manufacturer.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- The load of the system unit does not solely rely for support from the rackmounts located on the sides. Firm support from the bottom is highly necessary in order to provide balance stability.
- The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

## Installation Recommendations

Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.

Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A Philips screwdriver
- A flat-tipped screwdriver
- A grounding strap
- An anti-static pad

Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nose pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.



## Safety Precautions

1. Read these safety instructions carefully.
2. Keep this User Manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a stable surface during installation. Dropping it or letting it fall may cause damage.
7. The openings on the enclosure are for air convection to protect the equipment from overheating. DO NOT COVER THE OPENINGS.
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Place the power cord in a way so that people will not step on it. Do not place anything on top of the power cord. Use a power cord that has been approved for use with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
12. Never pour any liquid into an opening. This may cause fire or electrical shock.
13. Never open the equipment. For safety reasons, the equipment should be opened only by qualified service personnel.
14. If one of the following situations arises, get the equipment checked by service personnel:
  - a. The power cord or plug is damaged.
  - b. Liquid has penetrated into the equipment.
  - c. The equipment has been exposed to moisture.
  - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
  - e. The equipment has been dropped and damaged.
  - f. The equipment has obvious signs of breakage.
15. Do not place heavy objects on the equipment.
16. The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace your obsolete outlet.
17. **CAUTION:** DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.
18. Ensure to connect the power cord of the power adapter to a socket-outlet with earthing connection.

## Technical Support and Assistance

1. For the most updated information of NEXCOM products, visit NEXCOM's website at [www.nexcom.com](http://www.nexcom.com).
2. For technical issues that require contacting our technical support team or sales representative, please have the following information ready before calling:
  - Product name and serial number
  - Detailed information of the peripheral devices
  - Detailed information of the installed software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wordings of the error messages

### Warning!

1. Handling the unit: carry the unit with both hands and handle it with care.
2. Maintenance: to keep the unit clean, use only approved cleaning products or clean with a dry cloth.

## Conventions Used in this Manual



### Warning:

Information about certain situations, which if not observed, can cause personal injury. This will prevent injury to yourself when performing a task.



### Caution:

Information to avoid damaging components or losing data.



### Note:

Provides additional information to complete a task easily.

## Global Service Contact Information

### Headquarters

#### **NEXCOM International Co., Ltd.**

9F, No. 920, Chung-Cheng Rd.,  
Zhonghe District, New Taipei City, 23586,  
Taiwan, R.O.C.  
Tel: +886-2-8226-7786  
Fax: +886-2-8226-7782  
www.nexcom.com

### Asia

#### **Taiwan**

#### **NexAIoT Headquarters**

#### **Industry 4.0 and Cloud Services**

13F, No.916, Zhongzheng Rd.,  
Zhonghe District, New Taipei City,  
23586, Taiwan, R.O.C.  
Tel: +886-2-8226-7796  
Fax: +886-2-8226-7926  
Email: sales@nexaiot.com  
www.nexaiot.com

#### **NexAIoT Co., Ltd.**

#### **Taichung Office**

16F, No.250, Sec. 2, Chongde Rd.,  
Beitun District,  
Taichung City, 406, Taiwan, R.O.C.  
Tel: +886-4-2249-1179  
Fax: +886-4-2249-1172  
Email: sales@nexaiot.com  
www.nexaiot.com

#### **NexCOBOT Taiwan Co., Ltd.**

13F, No.916, Chung-Cheng Rd.,  
Zhonghe District,  
New Taipei City, 23586, Taiwan, R.O.C.  
Tel: +886-2-8226-7786  
Fax: +886-2-8226-7926  
Email: sales@nexcobot.com  
www.nexcobot.com

#### **GreenBase Technology Corp.**

13F, No.922, Chung-Cheng Rd.,  
Zhonghe District,  
New Taipei City, 23586, Taiwan, R.O.C.  
Tel: +886-2-8226-7786  
Fax: +886-2-8226-7900  
Email: sales@nexcom.com.tw  
www.nexcom.com.tw

#### **EMBUX Technology Co., Ltd.**

13F, No.916, Chung-Cheng Rd.,  
Zhonghe District,  
New Taipei City, 23586, Taiwan, R.O.C.  
Tel: +886-2-8226-7786  
Fax: +886-2-8226-7782  
Email: sales@nexcom.com.tw  
www.nexcom.com.tw

#### **TMR Technology Corp.**

13F, No.916, Chung-Cheng Rd.,  
Zhonghe District,  
New Taipei City, 23586, Taiwan, R.O.C.  
Tel: +886-2-8226-7786  
Fax: +886-2-8226-7782  
Email: sales@nexcom.com.tw  
www.nexcom.com.tw

### China

#### **NEXSEC Incorporated**

5F, No.4, No.7 Fengxian Middle Rd.,  
(Beike Industrial Park), Haidian District,  
Beijing, 100094, China  
Tel: +86-10-5704-2680  
Fax: +86-10-5704-2681  
Email: marketing@nexsec.cn  
www.nexsec.cn

#### **NEXCOM Shanghai**

No.4, 16 Building,  
Shanghai OMNI Tech & Science Park  
No. 1699, Douhui Rd.,  
Shanghai, 201108, China  
Tel: +86-21-5278-5868  
Fax: +86-21-3251-6358  
Email: sales@nexcom.cn  
www.nexcom.cn

## **NEXCOM Surveillance Technology Corp.**

5F, Building C, ZhenHan Industrial Zone,  
GanKeng Community, Buji Street,  
LongGang District,  
ShenZhen, 518112, China  
Tel: +86-755-8364-7768  
Fax: +86-755-8364-7738  
Email: steveyang@nexcom.com.tw  
www.nexcom.cn

## **NEXCOM United System Service**

Room 603/604, Huiyinmingzun Plaza Bldg. 1,  
No. 609, Yunlin East Rd.,  
Shanghai, 200062, China  
Tel: +86-21-5278-5868  
Fax: +86-21-3251-6358  
Email: renwang@nexcom.com.tw  
www.nexcom.cn

## **NEXGOL Chongqing**

1F, Building B4, Electronic 2nd Area,  
(Phoenix Lake Industrial Park), Yongchuan Dist.,  
Chongqing City, 402160, China  
Tel: +86-23-4960-9080  
Fax: +86-23-4966-5855  
Email: sales@nexgol.com.cn  
www.nexcobot.com/NexGOL

## **NexCOBOT China**

Room 501, Building 1, Haichuang Building,  
No.7 Qingyi Road, Guicheng Street,  
Nanhai District, Foshan City,  
Guangdong Province, 528314, China  
Tel: +86-757-8625-7118  
Email: sales@nexcobot.com  
www.nexcobot.com.cn

## **Beijing NexGemo Technology Co.,Ltd.**

5F, Gemotech Building, No.1, Development Rd.,  
Changping International Information Industry Base,  
Changping District,  
Beijing, 102206, China  
Tel: +86-10-8190-9328  
Fax: +86-10-8190-9456  
Email: sales@gemotech.cn  
www.nexgemo.cn

## **Japan**

### **NEXCOM Japan**

9F, Tamachi Hara Bldg.,  
4-11-5, Shiba Minato-ku,  
Tokyo, 108-0014, Japan  
Tel: +81-3-5419-7830  
Fax: +81-3-5419-7832  
Email: sales@nexcom-jp.com  
www.nexcom-jp.com

## **America**

### **USA NEXCOM USA**

46665 Fremont Blvd.,  
Fremont CA 94538, USA  
Tel: +1-510-656-2248  
Fax: +1-510-656-2158  
Email: sales@nexcom.com  
www.nexcomusa.com

## **Europe**

### **United Kingdom NEXCOM EUROPE**

10 Vincent Avenue,  
Crownhill Business Centre,  
Milton Keynes, Buckinghamshire  
MK8 0AB, United Kingdom  
Tel: +44-1908-267121  
Fax: +44-1908-262042  
Email: sales.uk@nexcom.eu  
www.nexcom.co.uk

## Package Contents

Before continuing, verify that the AIEdge-X®500 package that you received is complete. Your package should have all the items listed in the following table.

| Item | Name        | Qty |
|------|-------------|-----|
| 1    | Thermal Pad | 1   |
| 2    | Screw       | 1   |
| 3    | EPE         | 2   |
| 4    | Carton      | 1   |
| 5    | PE          | 1   |

## Ordering Information

The following below provides ordering information for AIEdge-X®500.

### **AIEdge-X®500 (P/N: 10W20X5000X0)**

Industrial AI Computer powered by 8th/9th Generation Intel® Core™ processor,  
with large storage and optional NVIDIA graphics card

# CHAPTER 1: PRODUCT INTRODUCTION

## AIEdge-X®500

### Overview



### Key Features

- LGA1151 socket for 8th/9th Generation Intel® Core™ processor (35W/65W)
- 4 x 2.5 inch HDD/SSD slots, support RAID 0/1/5/10
- Expandable PCIe x16/PCIe x4/PCI slots, perfect for graphics cards
- Suitable for all kinds of AI applications
- 1 x Intel® I219-LM GbE PHY and 1 x Intel® I211 Gigabit Ethernet Controller
- Supports Intel® AMT

# Hardware Specifications

## CPU Support

- Supports 8th/9th generation Intel® Core™ socket type processor up to 65W (LGA1151)
  - Intel® Core™ i3-8100T, 3.10 GHz, 4 Core, 35W
  - Intel® Core™ i5-8500T, 2.10 GHz, 6 Core, 35W
  - Intel® Core™ i7-8700T, 2.40 GHz, 6 Core, 35W
  - Intel® Core™ i3-9100TE, 2.20 GHz, 4 Core, 35W
  - Intel® Core™ i5-9500TE, 2.20 GHz, 6 Core, 35W
  - Intel® Core™ i7-9700TE, 1.80 GHz, 8 Core, 35W
  - Intel® Core™ i3-8300, 3.70 GHz, 4 Core, 65W
  - Intel® Core™ i5-8500, 3.00 GHz, 6 Core, 65W
  - Intel® Core™ i7-8700, 3.20 GHz, 6 Core, 65W
  - Intel® Core™ i3-9300, 3.70 GHz, 4 Core, 65W
  - Intel® Core™ i5-9500, 3.00 GHz, 6 Core, 65W
  - Intel® Core™ i7-9700, 3.00 GHz, 8 Core, 65W

## Chipset

- Intel® PCH Q370

## Graphics

- Intel® HD Graphics 630 series

## Main Memory

- 2 x 260-pin SO-DIMM sockets, support DDR4 2400/2666 non-ECC, unbuffered memory up to 64G (single socket max. 32GB)

## I/O Interface - Internal

- 3 x COM, support RS232
- 2 x USB 3.1 via box header
- 6 x USB 2.0 via JST connector
- 8-Channel GPIO

## I/O Interface - Front

- 1 x Power button with LED
- 1 x Reset button
- 1 x HDMI 2.0
- 2 x USB 3.0
- 1 x USB 2.0
- 2 x RJ45 with LEDs for Gigabit LAN (Intel® I219-LM GbE PHY and Intel® I211 Gigabit Ethernet controller)
- 1 x COM4, supports RS232/422/485

## Graphics & Display

- Intel® UHD Graphics 630 (internal)
- Optional NVIDIA graphics card display via PCIe x16 (up to RTX 3090)

## Graphics Card Dimensions

- Supports up to 327 x 140 x 55.6 mm card dimensions (350W GPU)

## Storage

- 4 x SATA 2.5" HDD/SSD with RAID 0/1/5/10
- M.2 2280 Key M (SATA/PCIe)



## Expansion

- 1 x PCIe x16 slot
- 1 x PCIe x4 slot
- 1 x PCI slot

## Power Supply

- 1 x internal 800W ATX power supply
- Input: 100VAC to 240VAC
- Output: +12VDC
- Supports AT/ATX via jumper setting (default: ATX)

## Environment

- Operating temperature: 0°C to 45°C (active cooling design)
- Storage temperature: -20°C to 80°C
- Humidity: 10 to 90% (non-condensing)
- Shock protection: 50G peak acceleration, 11ms according to IEC60068-2-27
- Vibration protection:
  - Random: 2Grms @ 5~500 Hz, IEC60068-2-64 (with SSD)
  - Sinusoidal: 2G @ 5~500 Hz, IEC60068-2-6 (with SSD)

## Certification

- CE Approval
- FCC Class A
- LVD


## Dimensions

- 360mm x 290mm x 150mm (L x W x H)


## Operating System

- Windows 10/Linux

## Physical Features



# Mechanical Dimensions



## CHAPTER 2: JUMPERS AND CONNECTORS

This chapter lists the locations of the jumpers and connectors for AIEdge-X®500.

### Before You Begin

- Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.
- Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:
  - A Philips screwdriver
  - A flat-tipped screwdriver
  - A set of jewelers screwdrivers
  - A grounding strap
  - An anti-static pad
- Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nosed pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.
- Before working on internal components, make sure that the power is off. Ground yourself before touching any internal components, by touching a metal object. Static electricity can damage many of the electronic components. Humid environments tend to have less static electricity than

dry environments. A grounding strap is warranted whenever danger of static electricity exists.

### Precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous.

Follow the guidelines below to avoid damage to your computer or yourself:


- Always disconnect the unit from the power outlet whenever you are working inside the case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Don't flex or stress the circuit board.
- Leave all components inside the static-proof packaging that they shipped with until they are ready for installation.
- Use correct screws and do not over tighten screws.

## Jumper Settings


A jumper is the simplest kind of electric switch. It consists of two metal pins and a cap. When setting the jumpers, ensure that the jumper caps are placed on the correct pins. When the jumper cap is placed on both pins, the jumper is short. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is open.

Refer to the illustrations below for examples of what the 2-pin and 3-pin jumpers look like when they are short (on) and open (off).

Two-Pin Jumpers: Open (Left) and Short (Right)




Three-Pin Jumpers: Pins 1 and 2 are Short




## Locations of the Jumpers and Connectors for AIEdge-X®500

The figure below is the top and bottom view of the mainboard used in AIEdge-X®500. It shows the locations of the jumpers and connectors.

### Top View



Bottom View





# Jumpers

## AT/ATX Mode Select

Connector type: 1x3 3-pin header, 2.54mm pitch  
Connector location: ATATX



| Pin    | Settings |
|--------|----------|
| 1-2 On | AT Mode  |
| 2-3 On | ATX Mode |

2-3 On: default





# Internal Connectors

## SPI Connector


Connector type: 2x4 8-pin header, 2.0mm pitch  
Connector location: SPI



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1   | NC         | 2   | S_RTCRST#  |
| 3   | +3V3_SPI   | 4   | GND        |
| 5   | SPI_CS#_R  | 6   | SPI_CLK_R  |
| 7   | SPI_DO_R   | 8   | SPI_DI_R   |

## Front Panel Connector

Connector type: 2x4 8-pin header, 2.54mm pitch  
Connector location: JFP1




| Pin | Definition   | Pin | Definition   |
|-----|--------------|-----|--------------|
| 1   | HDD_LED      | 2   | PWR_LED      |
| 3   | HDD_LED#     | 4   | GND          |
| 5   | GND          | 6   | SHB_PWR_BTN# |
| 7   | SHB_RST_BTN# | 8   | GND          |



DC IN Connector


Connector type: 1x3 3-pin Wafer, 3.96mm pitch  
Connector location: 5PW



| Pin | Definition |
|-----|------------|
| 1   | +5V        |
| 2   | GND        |
| 3   | +5V        |

12V Power Connector


Connector type: 2x2 4-pin header, 3.5mm pitch  
Connector location: ATX12V\_PWR1



| Pin | Definition |
|-----|------------|
| 1   | GND        |
| 2   | GND        |
| 3   | +12V       |
| 4   | +12V       |

CPU Fan Connector


Connector type: 1x4 4-pin Wafer, 2.54mm pitch  
Connector location: CPUF



| Pin | Definition |
|-----|------------|
| 1   | GND        |
| 2   | +12V       |
| 3   | FANIN1     |
| 4   | FANOUT1    |

System Fan Connector

Connector type: 1x4 4-pin Wafer, 2.54mm pitch  
Connector location: SYSF



| Pin | Definition |
|-----|------------|
| 1   | GND        |
| 2   | +12V       |
| 3   | FANIN2     |
| 4   | FANOUT2    |



### GPIO Connector

Connector type: 2x5 10-pin header, 2.0mm pitch  
Connector location: GPIO



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1   | +5VGPIO    | 2   | GND        |
| 3   | GPIO70     | 4   | GPIO71     |
| 5   | GPIO72     | 6   | GPIO73     |
| 7   | GPIO74     | 8   | GPIO75     |
| 9   | GPIO76     | 10  | GPIO77     |

### USB Connector

Connector type: 2x5 10-pin header, 2.54mm pitch  
Connector location: USB2\_1



| Pin | Definition  | Pin | Definition  |
|-----|-------------|-----|-------------|
| 1   | +5V_USB2_12 | 2   | +5V_USB2_12 |
| 3   | USB2N_5     | 4   | USB2N_6     |
| 5   | USB2P_5     | 6   | USB2P_6     |
| 7   | GND         | 8   | GND         |
|     |             | 10  | NC          |



USB Connector

Connector type: 2x5 10-pin header, 2.54mm pitch  
Connector location: USB2\_2



| Pin | Definition  | Pin | Definition  |
|-----|-------------|-----|-------------|
| 1   | +5V_USB2_12 | 2   | +5V_USB2_12 |
| 3   | USB2N_7     | 4   | USB2N_8     |
| 5   | USB2P_7     | 6   | USB2P_8     |
| 7   | GND         | 8   | GND         |
|     |             | 10  | NC          |

USB Connector

Connector type: 2x5 10-pin header, 2.54mm pitch  
Connector location: USB2\_3




| Pin | Definition  | Pin | Definition  |
|-----|-------------|-----|-------------|
| 1   | +5V_USB2_34 | 2   | +5V_USB2_34 |
| 3   | USB2N_9     | 4   | USB2N_10    |
| 5   | USB2P_9     | 6   | USB2P_10    |
| 7   | GND         | 8   | GND         |
|     |             | 10  | NC          |



COM Port Connector


Connector type: 1x9 9-pin header, 1.0mm pitch  
Connector location: COM1



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1   | COM_RI#    | 2   | COM_CTS#   |
| 3   | COM_RTS#   | 4   | COM_DSR#   |
| 5   | GND        | 6   | COM_DTR#   |
| 7   | COM_TXD    | 8   | COM_RXD    |
| 9   | COM_DCD#   |     |            |

COM Port Connector

Connector type: 1x9 9-pin header, 1.0mm pitch  
Connector location: COM2




| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1   | COM_RI#    | 2   | COM_CTS#   |
| 3   | COM_RTS#   | 4   | COM_DSR#   |
| 5   | GND        | 6   | COM_DTR#   |
| 7   | COM_TXD    | 8   | COM_RXD    |
| 9   | COM_DCD#   |     |            |





COM Port Connector


Connector type: 1x9 9-pin header, 1.0mm pitch  
Connector location: COM3



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1   | COM_RI#    | 2   | COM_CTS#   |
| 3   | COM_RTS#   | 4   | COM_DSR#   |
| 5   | GND        | 6   | COM_DTR#   |
| 7   | COM_TXD    | 8   | COM_RXD    |
| 9   | COM_DCD#   |     |            |

COM Port Connector

Connector type: 1x9 9-pin header, 1.0mm pitch  
Connector location: COM4



| Pin | Definition | Pin | Definition |
|-----|------------|-----|------------|
| 1   | +5V        | 2   | COM_CTS#   |
| 3   | COM_RTS#   | 4   | COM_DSR#   |
| 5   | GND        | 6   | COM_DTR#   |
| 7   | COM_TXD    | 8   | COM_RXD    |
| 9   | COM_DCD#   |     |            |





SATA Connector

Connector type: Standard Serial ATA 7P (1.27mm, SATA-M-180)  
Connector location: SATA1



| Pin | Definition  | Pin | Definition  |
|-----|-------------|-----|-------------|
| 1   | GND         | 2   | S_SATA_TXP0 |
| 3   | S_SATA_TXN0 | 4   | GND         |
| 5   | S_SATA_RXN0 | 6   | S_SATA_RXP0 |
| 7   | GND         |     |             |

SATA Connector

Connector type: Standard Serial ATA 7P (1.27mm, SATA-M-180)  
Connector location: SATA2



| Pin | Definition  | Pin | Definition  |
|-----|-------------|-----|-------------|
| 1   | GND         | 2   | S_SATA_TXP1 |
| 3   | S_SATA_TXN1 | 4   | GND         |
| 5   | S_SATA_RXN1 | 6   | S_SATA_RXP1 |
| 7   | GND         |     |             |







SATA Connector

Connector type: Standard Serial ATA 7P (1.27mm, SATA-M-180)  
Connector location: SATA3



| Pin | Definition  | Pin | Definition  |
|-----|-------------|-----|-------------|
| 1   | GND         | 2   | S_SATA_TXP2 |
| 3   | S_SATA_TXN2 | 4   | GND         |
| 5   | S_SATA_RXN2 | 6   | S_SATA_RXP2 |
| 7   | GND         |     |             |

SATA Connector

Connector type: Standard Serial ATA 7P (1.27mm, SATA-M-180)  
Connector location: SATA4



| Pin | Definition  | Pin | Definition  |
|-----|-------------|-----|-------------|
| 1   | GND         | 2   | S_SATA_TXP3 |
| 3   | S_SATA_TXN3 | 4   | GND         |
| 5   | S_SATA_RXN3 | 6   | S_SATA_RXP3 |
| 7   | GND         |     |             |



SATA Power Connector

Connector type: 1x2 2-pin header JST, 2.5mm pitch  
Connector location: SPWR1



| Pin | Definition |
|-----|------------|
| 1   | +5V        |
| 2   | GND        |

SATA Power Connector

Connector type: 1x2 2-pin header JST, 2.5mm pitch  
Connector location: SPWR2



| Pin | Definition |
|-----|------------|
| 1   | +5V        |
| 2   | GND        |



## 80 Port Connector

Connector type: 1x10 10-pin header, 1.0mm pitch  
Connector location: DEBUG




| Pin | Definition  | Pin | Definition     |
|-----|-------------|-----|----------------|
| 1   | GND         | 2   | PLTRST#_BUFF_1 |
| 3   | CLKOUT_LPC1 | 4   | LFRAME#        |
| 5   | LPC_D3      | 6   | LPC_D2         |
| 7   | LPC_D1      | 8   | LPC_D0         |
| 9   | SERIRQ_R    | 10  | +3V3           |



## M.2 Connector (M-Key)

Connector location: M2M\_2280



| Pin | Definition   | Pin | Definition |
|-----|--------------|-----|------------|
| 1   | GND          | 2   | +3VSB      |
| 3   | GND          | 4   | +3VSB      |
| 5   | S_PCIE_RXN20 | 6   | NC         |
| 7   | S_PCIE_RXP20 | 8   | NC         |
| 9   | GND          | 10  | DSS#_1     |
| 11  | PCIE_TXN20   | 12  | +3VSB      |
| 13  | PCIE_TXP20   | 14  | +3VSB      |
| 15  | GND          | 16  | +3VSB      |
| 17  | S_PCIE_RXN19 | 18  | +3VSB      |
| 19  | S_PCIE_RXP19 | 20  | NC         |
| 21  | GND          | 22  | NC         |
| 23  | PCIE_TXN19   | 24  | NC         |
| 25  | PCIE_TXP19   | 26  | NC         |
| 27  | GND          | 28  | NC         |
| 29  | S_PCIE_RXN18 | 30  | NC         |
| 31  | S_PCIE_RXP18 | 32  | NC         |
| 33  | GND          | 34  | NC         |
| 35  | PCIE_TXN18   | 36  | NC         |
| 37  | PCIE_TXP18   | 38  | DEVS_LP_0  |

| Pin | Definition        | Pin | Definition   |
|-----|-------------------|-----|--------------|
| 39  | GND               | 40  | NC           |
| 41  | S_PCIE_RXP17      | 42  | NC           |
| 43  | S_PCIE_RXN17      | 44  | NC           |
| 45  | GND               | 46  | NC           |
| 47  | PCIE_TXN17        | 48  | NC           |
| 49  | PCIE_TXP17        | 50  | PERST#1      |
| 51  | GND               | 52  | SRCLKREQ_N11 |
| 53  | S_CLKOUT_PCIE_N11 | 54  | PEWAKE_N1    |
| 55  | S_CLKOUT_PCIE_P11 | 56  | NC           |
| 57  | GND               | 58  | NC           |
|     |                   |     |              |
| 67  | NC                | 68  | SUSCLK2      |
| 69  | PEDET_1           | 70  | +3VSB        |
| 71  | GND               | 72  | +3VSB        |
| 73  | GND               | 74  | +3VSB        |
| 75  | GND               |     |              |


## CHAPTER 3: SYSTEM SETUP

### Removing the Two Top Covers from the Chassis




Prior to removing the chassis covers, make sure the unit's power is off and disconnected from the power sources to prevent electric shock or system damage.

1. Remove the six mounting screws around the chassis.





2. Slide out the two top covers, then lift up the covers to remove them.




## Installing a Memory Module

1. With the two top covers removed, loosen the four screws on the heat sink fan, then remove it to access the memory slots.
2. Release the locks on the memory slots.




3. Insert the module into the socket at a 90 degree angle. Apply firm even pressure to each end of the module until it slips into the slot. While pushing the module into position, the locks will close automatically.






## Installing a CPU

1. With the two top covers removed, loosen the four screws on the heat sink fan, then remove the heat sink.
2. The CPU socket is readily accessible after you have removed the heat sink.



**CPU Socket**


3. Unlock the socket by pushing the load lever down, moving it sideways until it is released from the retention tab; then lift the load lever up.




Load Lever

Retention Tab

4. Lifting the load lever will at the same time lift the load plate. After lifting the load lever, remove the protective cap from the CPU socket.



5. Insert the CPU into the socket. The triangular edge on the CPU must align with the corner of the CPU socket shown on the photo.



6. Close the load plate and then push the load lever down.

While closing the load plate, make sure the front edge of the load plate slides under the retention knob.




Do not force the CPU into the socket. Forcing the CPU into the socket may bend the pins and damage the CPU.




- Handle the CPU by its edges and avoid touching the pins.
- The CPU will fit in only one orientation and can easily be inserted without exerting any force.

7. Hook the load lever under the retention tab.





8. Reinstall the CPU heat sink fan with the four mounting screws removed earlier.




## Installing an Add-on Card

1. Remove the two screws on the brackets as shown below, then plug the add-on card (using a graphics card as an example in the following steps) into the PCIe slot.



2. Plug in the 6+2-pin power cable for the graphics card if necessary, then refasten the two screws on the graphics card bracket to secure the card firmly.





## Installing a 2.5" Storage Drive (External)

1. Locate the storage drive bay on the front panel. Unlock the drive bay by turning the screw lock to the unlocked position using the tool in the accessory pack.
2. Gently pull out the handle to release the drive bay cover, then insert the storage drive into the drive bay. Once the storage drive is fully seated inside the drive bay, close and resecure the cover.



## CHAPTER 4: BIOS SETUP

This chapter describes how to use the BIOS setup program for AIEdge X®500. The BIOS screens provided in this chapter are for reference only and may change if the BIOS is updated in the future.

To check for the latest updates and revisions, visit the NEXCOM website at [www.nexcom.com.tw](http://www.nexcom.com.tw).

### About BIOS Setup

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters.

These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

With easy-to-use pull down menus, you can configure items such as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

The settings made in the setup program affect how the computer performs. It is important, therefore, first to try to understand all the setup options, and second, to make settings appropriate for the way you use the computer.

### When to Configure the BIOS

- This program should be executed under the following conditions:
- When changing the system configuration
- When a configuration error is detected by the system and you are prompted to make changes to the setup program
- When resetting the system clock
- When redefining the communication ports to prevent any conflicts
- When making changes to the Power Management configuration
- When changing the password or making other changes to the security setup

Normally, CMOS setup is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.



## Default Configuration


Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

## Entering Setup












When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:

- If the error occurs before the display device is initialized, a series of beeps will be transmitted.
- If the error occurs after the display device is initialized, the screen will display the error message.

Powering on the computer and immediately pressing <Del> allows you to enter Setup.

Press the  key to enter Setup:


## Legends

| Key   | Function   |
|---|--|
|    | Moves the highlight left or right to select a menu.                      |
|    | Moves the highlight up or down between sub-menus or fields.              |
|    | Exits the BIOS Setup Utility.  |
|    | Scrolls forward through the values or options of the highlighted field.  |
|    | Scrolls backward through the values or options of the highlighted field. |
|    | Selects a field.   |
|    | Displays General Help.   |
|    | Load previous values.  |
|    | Load optimized default values.   |
|   | Saves and exits the Setup program.                                       |
|  | Press <Enter> to enter the highlighted sub-menu                          |


## Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

## Submenu


When “▶” appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press  .

# BIOS Setup Utility

Once you enter the AMI BIOS Setup Utility, the Main Menu will appear on the screen. The main menu allows you to select from several setup functions and one exit. Use arrow keys to select among the items and press  to accept or enter the submenu.

## Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



## System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Monday to Sunday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 2005 to 2099.

## System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.

Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.



Setting incorrect field values may cause the system to malfunction.

Aptio Setup Utility - Copyright (C) 2020 American Megatrends, Inc.

MainAdvancedChipsetSecurityBootSave & Exit

▶ CPU Configuration

▶ Power & Performance

▶ PCH-FW Configuration

▶ Trusted Computing

▶ IT8786 Super IO Configuration

▶ Hardware Monitor

▶ S5 RTC Wake Settings

▶ USB Configuration

▶ NVMe Configuration

▶ Network Stack Configuration

CPU Configuration Parameters

←→: Select Screen  
↑↓: Select Item  
Enter: Select  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F3: Optimized Defaults  
F4: Save & Exit  
ESC: Exit

Version 2.20.1275, Copyright (C) 2020 American Megatrends, Inc.

CPU Configuration

This section is used to view CPU status and configure CPU parameters.

Aptio Setup Utility - Copyright (C) 2020 American Megatrends, Inc.

Advanced

CPU Configuration

|                      |                        |
|----------------------|------------------------|
| Type                 | Intel(R) Core(TM)      |
| ID                   | i5-8500T CPU @ 2.10GHz |
| Speed                | 0x906EA                |
| L1 Data Cache        | 2100 MHz               |
| L1 Instruction Cache | 32 KB x 6              |
| L2 Cache             | 32 KB x 6              |
| L3 Cache             | 256 KB x 6             |
| L4 Cache             | 9 MB                   |
| VMX                  | N/A                    |
| SMX/TXT              | Supported              |

Intel (VMX) Virtualization Technology

[Enabled]

Active Processor Cores

[All]

When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

←→: Select Screen  
↑↓: Select Item  
Enter: Select  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F3: Optimized Defaults  
F4: Save & Exit  
ESC: Exit

Version 2.20.1275, Copyright (C) 2020 American Megatrends, Inc.

Intel® (VMX) Virtualization Technology

When this field is set to Enabled, the VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

Active Processor Cores

Select the number of cores to enable in each processor package.

NEXCOM

Copyright © 2021 NEXCOM International Co., Ltd. All Rights Reserved.

38

AIEdge-X\*500 User Manual



Power & Performance

This section is used to configure the CPU power management features.



CPU - Power Management Control

Enters the CPU - Power Management Control submenu.

CPU - Power Management Control



Intel® SpeedStep™

Enables or disables Intel Speedstep technology.

Turbo Mode

Enables or disables turbo mode.

C states

Enable CPU C States Support for power saving. It is recommended to keep C3, C6 and C7 all enabled for better power saving.

## PCH-FW Configuration

This section is used to configure the firmware update options.



### ME State

Enables or disables ME state. When disabled, ME will be placed into ME Temporarily Disabled Mode.

### Manageability Features State

Enables or disables Manageability Features State.

### AMT BIOS Features

When disabled, AMT BIOS Features are no longer supported and user is no longer able to access MEBx Setup. Please note that this option does not disable Manageability Features in FW.

### ME Unconfig on RTC Clear

When disabled, ME will not be unconfigured on RTC Clear.



AMT Configuration

Aptio Setup Utility - Copyright (C) 2020 American Megatrends, Inc.

Advanced

|                              |            |   |
|------------------------------|------------|---|
| ASF support                  | [Enabled]  | Enable/Disable Alert Standard Format support. |
| USB Provisioning of AMT      | [Disabled] |   |
| ▶ CIRA Configuration         |            |   |
| ▶ ASF Configuration          |            |   |
| ▶ Secure Erase Configuration |            |   |
| ▶ OEM Flags Settings         |            |   |
| ▶ MEBx Resolution Settings   |            |   |

→←: Select Screen  
↑↓: Select Item  
Enter: Select  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F3: Optimized Defaults  
F4: Save & Exit  
ESC: Exit

Version 2.20.1275. Copyright (C) 2020 American Megatrends, Inc.

ASF support

Enables or disables Alert Standard Format support.

USB Provisioning of AMT

Enables or disables USB Provisioning of AMT.

Firmware Update Configuration

Aptio Setup Utility - Copyright (C) 2020 American Megatrends, Inc.

Advanced

|                      |            |   |
|----------------------|------------|---|
| Me FW Image Re-Flash | [Disabled] | Enable/Disable Me FW Image Re-Flash function. |
|----------------------|------------|---|

→←: Select Screen  
↑↓: Select Item  
Enter: Select  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F3: Optimized Defaults  
F4: Save & Exit  
ESC: Exit


Version 2.20.1275. Copyright (C) 2020 American Megatrends, Inc.

Me FW Image Re-Flash

Enables or disables the ME firmware image re-flash function.

## Trusted Computing

This section is used to configure Trusted Platform Module (TPM) settings.



### Security Device Support

Enables or disables BIOS support for security device. O.S will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

### SHA-1 PCR Bank

Enables or disables SHA-1 PCR Bank.

### SHA256 PCR Bank

Enables or disables SHA256 PCR Bank.

### Pending operation

Schedules an operation for the security device.

### Platform Hierarchy

Enables or disables Platform Hierarchy.

### Storage Hierarchy

Enables or disables Storage Hierarchy.

### Endorsement Hierarchy

Enables or disables Endorsement Hierarchy.

### TPM2.0 UEFI Spec Version

Configures the TPM2.0 UEFI spec version.

TCG\_1\_2: The compatible mode for Windows 8/Windows 10.  
 TCG\_2: Support new TCG2 protocol and event format for Windows 10 or later.

### Physical Presence Spec Version

Configures which physical presence spec version the OS will support. Please note that some HCK tests might not support 1.3.

### Device Select


TPM 1.2 will restrict support to TPM 1.2 devices. TPM 2.0 will restrict support to TPM 2.0 devices. Auto will support both TPM 1.2 and 2.0 devices with the default set to TPM 2.0 devices if not found, and TPM 1.2 devices will be enumerated.





### IT8786 Super IO Configuration

This section is used to configure the serial ports.




#### Super IO Chip

Displays the Super I/O chip used on the board.

### Serial Port 1 Configuration

This section is used to configure serial port 1.



#### Serial Port

Enables or disables the serial port.

## Serial Port 4 Configuration

This section is used to configure serial port 4.



### Serial Port

Enables or disables the serial port.

### Onboard Serial Port 4 Mode


Select this to change the serial port mode to RS232, RS422 or RS485.

### Terminal resistor

Enables or disables the terminal resistor.

## Hardware Monitor

This section is used to monitor hardware status such as temperature, fan speed and voltages.



### CPU temperature

Detects and displays the current CPU temperature.

### System temperature

Detects and displays the current system temperature.

### CPU FAN and SYSTEM FAN


Detects and displays the current fan speed of the CPU fan and system fan.

### Vcore to +3V3

Detects and displays the output voltages.



Smart Fan Function




CPU Fan Mode

Configures the fan mode of the CPU fan.

S5 RTC Wake Settings

This section is used to configure system to wake from S5 using RTC alarm.




Wake System from S5

Enables or disables system wake on alarm event. When FixedTime is selected, system will wake on the hr::min::sec specified. When DynamicTime is selected, system will wake on the current time + Increase minute(s).



## USB Configuration

This section is used to configure the USB.



## USB Mass Storage Driver Support

Enables or disables USB mass storage driver support.

## USB transfer time-out

The time-out value for control, bulk, and interrupt transfers.

## Device reset time-out

Selects the USB mass storage device's start unit command timeout.

## Device power-up delay

Maximum time the value will take before it properly reports itself to the Host Controller. "Auto" uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

## Legacy USB Support

Enable Enables Legacy USB.

Auto Disables support for Legacy when no USB devices are connected.

Disable Keeps USB devices available only for EFI applications.


## XHCI Hand-off

This is a workaround for OSs that does not support XHCI hand-off. The XHCI ownership change should be claimed by the XHCI driver.




### NVMe Configuration

This section is used to display information on the NVMe devices installed.



### Network Stack Configuration

This section is used to configure the network stack.



#### Network Stack

Enables or disables UEFI network stack.





## Chipset

This section gives you functions to configure the system based on the specific features of the chipset. The chipset manages bus speeds and access to system memory resources.



### System Agent (SA) Configuration

System Agent (SA) parameters.

### PCH-IO Configuration

PCH-IO parameters.

## System Agent (SA) Configuration

This section is used to configure the System Agent (SA) configuration.



### Graphics Configuration

Enters the Graphics Configuration submenu.

### PEG Port Configuration

Enters the PEG Port Configuration submenu.



PEG Port Configuration



Enable Root Port

Enables or disables the root port.

Max Link Speed

Configures the maximum link speed of the PEG device.

PCH-IO Configuration

This section is used to configure PCH-IO configuration.



PCH LAN Controller

Enables or disables onboard NIC.

Wake on LAN Enable

Enables or disables integrated LAN to wake the system.

State After G3

Configures the power state when power is re-applied after a power failure (G3 state).

## Security

| Aptio Setup Utility - Copyright (C) 2020 American Megatrends, Inc.   |          |  |          |      |             |
|--|----------|--|----------|------|-------------|
| Main   | Advanced | Chipset  | Security | Boot | Save & Exit |
| <b>Password Description</b><br><br>If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup.<br>If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights.<br>The password length must be in the following range:<br>Minimum length                      3<br>Maximum length                      20 |          | Set Administrator Password   |          |      |             |
| Administrator Password<br>User Password  |          | →←: Select Screen<br>↑↓: Select Item<br>Enter: Select<br>+/-: Change Opt.<br>F1: General Help<br>F2: Previous Values<br>F3: Optimized Defaults<br>F4: Save & Exit<br>ESC: Exit |          |      |             |

Version 2.20.1275. Copyright (C) 2020 American Megatrends, Inc.

### Administrator Password

Select this to reconfigure the administrator's password.

### User Password

Select this to reconfigure the user's password.

## Boot

| Aptio Setup Utility - Copyright (C) 2020 American Megatrends, Inc.   |          |  |          |      |             |
|--|----------|--|----------|------|-------------|
| Main   | Advanced | Chipset  | Security | Boot | Save & Exit |
| <b>Boot Configuration</b><br>Setup Prompt Timeout                      1<br>[Off]<br>Bootup NumLock State                      [Enabled]<br>Quiet Boot |          | Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting.  |          |      |             |
| <b>Boot Option Priorities</b><br>Boot Option #1                      [UEFI: Built-in EFI Shell]  |          | →←: Select Screen<br>↑↓: Select Item<br>Enter: Select<br>+/-: Change Opt.<br>F1: General Help<br>F2: Previous Values<br>F3: Optimized Defaults<br>F4: Save & Exit<br>ESC: Exit |          |      |             |

Version 2.20.1275. Copyright (C) 2020 American Megatrends, Inc.

### Setup Prompt Timeout

Selects the number of seconds to wait for the setup activation key. 65535(0xFFFF) denotes indefinite waiting.

### Bootup NumLock State

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.

### Quiet Boot

|          |   |
|----------|---|
| Enabled  | Displays OEM logo instead of the POST messages. |
| Disabled | Displays normal POST messages.                  |

### Boot Option Priorities

Adjust the boot sequence of the system. Boot Option #1 is the first boot device that the system will boot from, next will be #2 and so forth.



## Save & Exit



### Save Changes and Exit

To save the changes and exit the Setup utility, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes. You can also press <F4> to save and exit Setup.

### Discard Changes and Exit

To exit the Setup utility without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting. You can also press <ESC> to exit without saving the changes.

### Save Changes and Reset

To save the changes and reset, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

### Discard Changes and Reset

To exit the Setup utility and reset without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting.

### Save Changes

To save changes and continue configuring the BIOS, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

### Discard Changes

To discard the changes, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes to discard all changes made and restore the previously saved settings.

### Restore Defaults

To restore the BIOS to default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

### Save as User Defaults

To use the current configurations as user default settings for the BIOS, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

### Restore User Defaults

To restore the BIOS to user default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

### Boot Override

To bypass the boot sequence from the Boot Option List and boot from a particular device, select the desired device and press <Enter>.