

NEXCOM International Co., Ltd.

## Network and Communication Solutions Fixed Wireless Access Telecom Appliance FTA 1170 Series User Manual

**NEXCOM International Co., Ltd.** Published November 2023



## CONTENTS

### Preface

Copyright	iv
Disclaimer	iv
Acknowledgements	iv
Regulatory Compliance Statements	iv
Declaration of Conformity	iv
RoHS Compliance	v
Warranty and RMA	vi
Safety Information	viii
Installation Recommendations	viii
Safety Precautions	ix
Technical Support and Assistance	x
Conventions Used in this Manual	x
Global Service Contact Information	xi
Package Contents	xiii

### **Chapter 1: Product Introduction**

Overview	1
Key Features	1
Hardware Specifications	2
Knowing Your FTA1170	3
Front Panel	3
Rear Panel	4

#### **Chapter 2: Jumpers and Connectors**

Before You Begin	5
Precautions	5
Jumper Settings	6
Locations of the Mainbaord Jumpers and Connectors	7
FTA 1170 Main Board Top View	7
Jumpers	8
SYS RTC Header Clear	8
CMOS Header	8
JTAG SEL Header	9
Connector Pin Definitions	10
PSU Power Control Connector	10
Mini PCIe Slot	11
SATA Connector	12
CPLD GPIO Header	12
CPLD GPIO Header	13
M.2 2280 Key M PCIe Slot	14
Intel XDP Connector (for Debug)	16
Board to Board Connector (Low Speed)	17
12V Power Connector	19
SATA Power Connector	19
Run BMC SO-DIMM Connector	20
FAN Wafer Connector	24
PCle Gen3 x16 Riser Card Board to Board Connector	25



Board to Board Connector (High Speed)	28
Core Power PWM SMBus Header	31
NAC Power PWM SMBus Header	31
CPLD JTAG Header	32
LPC TPM Module Header	32
CPLD JTAG Header	33
Locations of the Extension Board Connectors	34
FTA 1170 Extension Board Top View	34
Locations of the Mainbaord Jumpers and Connectors	34
FTA1170 Main Board Top View	34
Connector Pin Definitions	35
PoE Power Connector (only 54V supply)	35
Board to Board Connector (Low Speed)	37
Board to Board Connector (High Speed)	39
Reset Button Header	42
Power Button Header	42
PoE Box Header (Connector to PoE module)	43
I/O Board CPLD JTAG Header	47
Block Diagram	48
FTA1170	48
FTA1170A	49

## Chapter 3: System Setup

Removing the Chassis Cover	20
Installing Memory Modules	21
Installing an M.2 Key M Storage Device	22
Installing a BMC Module	24
Installing a 2.5" SATA Hard Drive	26

## **Chapter 4: BIOS Setup**

About BIOS Setup	20
When to Configure the BIOS	20
Default Configuration	21
Entering Setup	21
Legends	21
BIOS Setup Utility	23
Main	23
Advanced	24
Platform Configuration	33
Socket Configuration	
Security	46
Boot	47
Save & Exit	48



## PREFACE

## Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written consent from NEXCOM International Co., Ltd.

## Disclaimer

NE:COM

The information in this document is subject to change without prior notice and does not represent commitment from NEXCOM International Co., Ltd. However, users may update their knowledge of any product in use by constantly checking its manual posted on our website: http://www.nexcom.com. NEXCOM shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of any product, nor for any infringements upon the rights of third parties, which may result from such use. Any implied warranties of merchantability or fitness for any particular purpose is also disclaimed.

## Acknowledgements

FTA 1170 is a trademark of NEXCOM International Co., Ltd. All other product names mentioned herein are registered trademarks of their respective owners.

## **Regulatory Compliance Statements**

This section provides the FCC compliance statement for Class B devices and describes how to keep the system CE compliant.

## **Declaration of Conformity**

#### FCC

This equipment has been tested and verified to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. Operation of this equipment in a residential area (domestic environment) is likely to cause harmful interference, in which case the user will be required to correct the interference (take adequate measures) at their own expense.

#### CE

The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.



## **RoHS Compliance**



#### NEXCOM RoHS Environmental Policy and Status Update

NEXCOM is a global citizen for building the digital infrastructure. We are committed to providing green products and services, which are compliant with

European Union RoHS (Restriction on Use of Hazardous Substance in Electronic Equipment) directive 2011/65/EU, to be your trusted green partner and to protect our environment.

RoHS restricts the use of Lead (Pb) < 0.1% or 1,000ppm, Mercury (Hg) < 0.1% or 1,000ppm, Cadmium (Cd) < 0.01% or 100ppm, Hexavalent Chromium (Cr6+) < 0.1% or 1,000ppm, Polybrominated biphenyls (PBB) < 0.1% or 1,000ppm, and Polybrominated diphenyl Ethers (PBDE) < 0.1% or 1,000ppm.

In order to meet the RoHS compliant directives, NEXCOM has established an engineering and manufacturing task force in to implement the introduction of green products. The task force will ensure that we follow the standard NEXCOM development procedure and that all the new RoHS components and new manufacturing processes maintain the highest industry quality levels for which NEXCOM are renowned.

The model selection criteria will be based on market demand. Vendors and suppliers will ensure that all designed components will be RoHS compliant.

#### How to recognize NEXCOM RoHS Products?

For existing products where there are non-RoHS and RoHS versions, the suffix "(LF)" will be added to the compliant product name.

All new product models launched after January 2013 will be RoHS compliant. They will use the usual NEXCOM naming convention.



## Warranty and RMA

#### **NEXCOM Warranty Period**

NEXCOM manufactures products that are new or equivalent to new in accordance with industry standard. NEXCOM warrants that products will be free from defect in material and workmanship for 2 years, beginning on the date of invoice by NEXCOM.

#### **NEXCOM Return Merchandise Authorization (RMA)**

- Customers shall enclose the "NEXCOM RMA Service Form" with the returned packages.
- Customers must collect all the information about the problems encountered and note anything abnormal or, print out any on-screen messages, and describe the problems on the "NEXCOM RMA Service Form" for the RMA number apply process.
- Customers can send back the faulty products with or without accessories (manuals, cable, etc.) and any components from the card, such as CPU and RAM. If the components were suspected as part of the problems, please note clearly which components are included. Otherwise, NEXCOM is not responsible for the devices/parts.
- Customers are responsible for the safe packaging of defective products, making sure it is durable enough to be resistant against further damage and deterioration during transportation. In case of damages occurred during transportation, the repair is treated as "Out of Warranty."
- Any products returned by NEXCOM to other locations besides the customers' site will bear an extra charge and will be billed to the customer.

#### **Repair Service Charges for Out-of-Warranty Products**

NEXCOM will charge for out-of-warranty products in two categories, one is basic diagnostic fee and another is component (product) fee.

#### System Level

- Component fee: NEXCOM will only charge for main components such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistor, capacitor.
- Items will be replaced with NEXCOM products if the original one cannot be repaired. Ex: motherboard, power supply, etc.
- Replace with 3rd party products if needed.
- If RMA goods can not be repaired, NEXCOM will return it to the customer without any charge.

#### **Board Level**

- Component fee: NEXCOM will only charge for main components, such as SMD chip, BGA chip, etc. Passive components will be repaired for free, ex: resistors, capacitors.
- If RMA goods can not be repaired, NEXCOM will return it to the customer without any charge.



#### Warnings

Read and adhere to all warnings, cautions, and notices in this guide and the documentation supplied with the chassis, power supply, and accessory modules. If the instructions for the chassis and power supply are inconsistent with these instructions or the instructions for accessory modules, contact the supplier to find out how you can ensure that your computer meets safety and regulatory requirements.

#### Cautions

Electrostatic discharge (ESD) can damage system components. Do the described procedures only at an ESD workstation. If no such station is available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the computer chassis.



## **Safety Information**

Before installing and using the device, note the following precautions:

- Read all instructions carefully.
- Do not place the unit on an unstable surface, cart, or stand.
- Follow all warnings and cautions in this manual.
- When replacing parts, ensure that your service technician uses parts specified by the manufacturer.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- The load of the system unit does not solely rely for support from the rackmounts located on the sides. Firm support from the bottom is highly necessary in order to provide balance stability.
- The computer is provided with a battery-powered real-time clock circuit. There is a danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.

## **Installation Recommendations**

Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.

Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:

- A Philips screwdriver
- A flat-tipped screwdriver
- A grounding strap
- An anti-static pad

Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nose pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.



## **Safety Precautions**

- 1. Read these safety instructions carefully.
- 2. Keep this User Manual for later reference.
- 3. Disconnect this equipment from any AC outlet before cleaning. Use a damp cloth. Do not use liquid or spray detergents for cleaning.
- 4. For plug-in equipment, the power outlet socket must be located near the equipment and must be easily accessible.
- 5. Keep this equipment away from humidity.
- 6. Put this equipment on a stable surface during installation. Dropping it or letting it fall may cause damage.
- 7. The openings on the enclosure are for air convection to protect the equipment from overheating. DO NOT COVER THE OPENINGS.
- 8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
- 9. Place the power cord in a way so that people will not step on it. Do not place anything on top of the power cord. Use a power cord that has been approved for use with the product and that it matches the voltage and current marked on the product's electrical range label. The voltage and current rating of the cord must be greater than the voltage and current rating marked on the product.
- 10. All cautions and warnings on the equipment should be noted.
- 11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient overvoltage.
- 12. Never pour any liquid into an opening. This may cause fire or electrical shock.
- 13. Never open the equipment. For safety reasons, the equipment should be opened only by skilled person.

- 14. If one of the following situations arises, get the equipment checked by service personnel:
  - a. The power cord or plug is damaged.
  - b. Liquid has penetrated into the equipment.
  - c. The equipment has been exposed to moisture.
  - d. The equipment does not work well, or you cannot get it to work according to the user's manual.
  - e. The equipment has been dropped and damaged.
  - f. The equipment has obvious signs of breakage.
- 15. Do not place heavy objects on the equipment.
- 16. The unit uses a three-wire ground cable which is equipped with a third pin to ground the unit and prevent electric shock. Do not defeat the purpose of this pin. If your outlet does not support this kind of plug, contact your electrician to replace your obsolete outlet.
- 17. CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE RECOMMENDED BY THE MANUFACTURER. DISCARD USED BATTERIES ACCORDING TO THE MANUFACTURER'S INSTRUCTIONS.

"ATTENTION: Risque d'explosion si la batterie est remplacée par un type incorrect. Mettre au rebus les batteries usagées selon les instructions."

18. This equipment is not suitable for use in locations where children are likely to be present.

Cet équipement ne convient pas à une utilisation dans des lieux pouvant accueillir des enfants.

19. Suitable for installation in Information Technology Rooms in accordance with Article 645 of the National Electrical Code and NFPA 75.

Peut être installé dans des salles de matériel de traitement de l'information conformément à l'article 645 du National Electrical Code et à la NFPA 75.

20. Use certified and rated Laser Class I for Optical Transceiver product.



## **Technical Support and Assistance**

- 1. For the most updated information of NEXCOM products, visit NEXCOM's website at www.nexcom.com.
- 2. For technical issues that require contacting our technical support team or sales representative, please have the following information ready before calling:
  - Product name and serial number
  - Detailed information of the peripheral devices
  - Detailed information of the installed software (operating system, version, application software, etc.)
  - A complete description of the problem
  - The exact wordings of the error messages

#### Warning!

- 1. Handling the unit: carry the unit with both hands and handle it with care.
- 2. Maintenance: to keep the unit clean, use only approved cleaning products or clean with a dry cloth.

## **Conventions Used in this Manual**



#### Warning:

Information about certain situations, which if not observed, can cause personal injury. This will prevent injury to yourself when performing a task.



#### Caution:

Information to avoid damaging components or losing data.

Note:

Provides additional information to complete a task easily.



## **Global Service Contact Information**

#### Headquarters NEXCOM International Co., Ltd.

9F, No. 920, Zhongzheng Rd., Zhonghe District, New Taipei City, 23586, Taiwan, R.O.C. Tel: +886-2-8226-7786 Fax: +886-2-8226-7782 www.nexcom.com

## Asia

#### Taiwan NexAloT Headquarters Industry 4.0 and Cloud Services

13F, No.922, Zhongzheng Rd., Zhonghe District, New Taipei City, 23586, Taiwan, R.O.C. Tel: +886-2-8226-7796 Fax: +886-2-8226-7926 Email: jacobhuang@nexaiot.com www.nexaiot.com

#### NexAloT Co., Ltd. Taichung Office

NECOM

16F, No.250, Sec.2, Chongde Rd., Beitun District, Taichung City, 406, Taiwan, R.O.C. Tel: +886-4-2249-1179 Fax: +886-4-2249-1172 Email: jacobhuang@nexaiot.com www.nexaiot.com

#### NexCOBOT Taiwan Co., Ltd.

13F, No.916, Zhongzheng Rd., Zhonghe District, New Taipei City, 23586, Taiwan, R.O.C. Tel: +886-2-8226-7786 Fax: +886-2-8226-7926 Email: jennyshern@nexcobot.com www.nexcobot.com

#### GreenBase Technology Corp.

13F, No.922, Zhongzheng Rd., Zhonghe District, New Taipei City, 23586, Taiwan, R.O.C. Tel: +886-2-8226-7786 Fax: +886-2-8226-7900 Email: vivianlin@nexcom.com.tw www.nexcom.com.tw

#### DivioTec Inc.

19F-1A, No.97, Sec.4, ChongXin Rd., Sanchong District, New Taipei City, 24161, Taiwan, R.O.C. Tel: +886-2-8976-3077 Email: sales@diviotec.com www.diviotec.com

#### AloT Cloud Corp.

13F, No.922, Zhongzheng Rd., Zhonghe District, New Taipei City, 23586, Taiwan, R.O.C. Tel: +886-2-8226-7786 Fax: +886-2-8226-7782 Email: alantsai@aiotcloud.net www.aiotcloud.dev

#### EMBUX TECHNOLOGY CO., LTD.

13F, No.916, Zhongzheng Rd., Zhonghe District, New Taipei City, 23586, Taiwan, R.O.C. Tel: +886-2-8226-7786 Fax: +886-2-8226-7782 Email: info@embux.com www.embux.com

#### TMR TECHNOLOGIES CO., LTD.

13F, No.916, Zhongzheng Rd., Zhonghe District, New Taipei City, 23586, Taiwan, R.O.C. Tel: +886-2-8226-7786 Fax: +886-2-8226-7782 Email: services@tmrtek.com www.tmrtek.com



#### China NEXSEC Incorporated

201, Floor 2, Unit 2, Building 15, Yard 3, Gaolizhang Road, Haidian District, Beijing, 100094, China Tel: +86-10-5704-2680 Fax: +86-10-5704-2681 Email: marketing@nexsec.cn www.nexsec.cn

#### **NEXCOM Shanghai**

Room 406-407, Building C, No 154, Lane 953, Jianchuan Road, Minhang District, Shanghai, 201108, China Tel: +86-21-5278-5868 Fax: +86-21-3251-6358 Email: sales@nexcom.cn www.nexcom.cn

#### NEXCOM Surveillance Technology Corp.

Floor 8, Building B3, Xiufeng Industrial Zone, GanKeng Community, Buji Street, LongGang District, ShenZhen, 518112, China Tel: +86-755-8364-7768 Fax: +86-755-8364-7738 Email: steveyang@nexcom.com.tw www.nexcom.cn

## **NEXGOL** Chongqing

1st Building No.999, Star Boulevard, Yongchuan Dist, Chongqing City, 402160, China Tel: +86-23-4960-9080 Fax: +86-23-4966-5855 Email: sales@nexgol.com.cn www.nexcom.cn

#### Beijing NexGemo Technology Co.,Ltd.

Room 205, No.1, Fazhan Rd., Beijing International Information Industry Base, Changping District, Beijing, 102206, China Tel: +86-10-8072-2025 Fax: +86-10-8072-2022 Email: sales@nexgemo.cn www.nexgemo.com

#### Japan NEXCOM Japan

9F, Tamachi Hara Bldg., 4-11-5, Shiba Minato-ku, Tokyo, 108-0014, Japan Tel: +81-3-5419-7830 Fax: +81-3-5419-7832 Email: sales@nexcom-jp.com www.nexcom-jp.com

#### America USA NEXCOM USA

46665 Fremont Blvd., Fremont CA 94538, USA Tel: +1-510-656-2248 Fax: +1-510-656-2158 Email: sales@nexcom.com www.nexcomusa.com



## **Package Contents**

Before continuing, verify that the FTA 1170 series package that you received is complete. Your FTA 1170 series package should have all the items listed in the table below.

Item	Part Number	Name	Qty
1	50/0210036200	EAR SET FOR NSA5181 VER:A PANADVANCE 53.85x43x22mm SECC T=2.0mm PANTING PANTONE	1
	J0402100J0X00	2950	I
2	5044440031X00	RUBBER FOOT KANG YANG:RF20-5-4P	1
3	6023309081X00	CABLE EDI:232091081804-RS	1
4	5040150001X00	NSA7135 AL HANDLE VER:A PANADVANCE	1



## CHAPTER 1: PRODUCT INTRODUCTION

## **Overview**



## **Key Features**

- Intel Atom<sup>®</sup> P5300 processor series SoC, BGA type
- 4 x 288-pin DDR4 DIMM socket
- 1 x mini-PCIe slot for Wi-Fi 6 module
- 1 x M.2 3052 Key B for 5G FR1 module
- 1 x SO-DIMM DDR4 260-pin for BMC module



- 24 x 2.5GbE RJ45 switch ports
- 4 x 10GbE RJ45 NIC ports
- 2 x 10GbE SFP+ switch ports
- 2 x 10GbE SFP+ NIC ports
- 1 x PCIe Gen3 x16 interface LAN module slot



## **Hardware Specifications**

#### **Main Board**

 Intel Atom<sup>®</sup> processor P5300 SoC, BGA type, 8-24 cores (up to 85W), w/ Intel<sup>®</sup> QAT

#### **Main Memory**

4 x DDR4 2933 ECC RDIMM, UDIMM sockets, max. memory capacity up to 256GB for RDIMM and 128GB for UDIMM

#### **Storage Device**

- 1 x 8G eMMC 5.1 onboard
- 2 x 2.5" internal SSD/HDD
- 1 x M.2 2280 NVMe (Key M, PCle x4)

#### **Interface External**

- Button: reset
- LED for power/HDD/LAN/5G/Wi-Fi 6/PoE status
- 1 x RJ45 console port
- 1 x RJ45 management port
- 2 x USB 3.0 port
- 1 x nano-SIM slot
- 24 x 2.5GbE switch ports with PoE+ (FTA 1170) /24 x 2.5GbE switch ports (FTA 1170A)
- 4 x 10GbE RJ45 NIC with PoE+ (FTA 1170)/ 4 x 10GbE RJ45 NIC ports (FTA 1170A)
- 2 x 10GbE SFP+ switch ports
- 2 x 10GbE SFP+ NIC ports
- 8 x SMA connectors (front: 4 x for 5G/4G LTE, 2 x for Wi-Fi 5/6 antennas; back: 2 x for Wi-Fi 5/6 antennas)
- 1 x PCIe Gen3 x16 interface LAN module slot

#### **Interface Internal**

- 1 x mini-PCIe slot for Wi-Fi 6
- 1 x M.2 3052 Key B for 5G
- 1 x SO-DIMM DDR4 260-pin for IPMI module
- 4 x SPI connectors for PoE+ modules
- 1 x TPM header

#### Power

- 1 x CRPS 550W 12V AC PSU + 1 x CRPS 1000W 54V PoE+ PSU (FTA 1170)
- 2 x CRPS 550W 12V AC Redundant PSU (FTA 1170A)

#### **Dimension and Weight**

- Chassis dimension (mm): 438mm x 542 mm x 44mm (W x D x H)
- Package dimension(mm): 570mm x 741 mm x 226mm (W x D x H)
- Without packing: 10.1Kg
- With packing: 12.1kg

#### Environment

- Operating temperature: 0°C~40°C
- Storage temperature: -20°C~80°C
- Relative humidity: 10%~90% non-condensing

#### Certifications

- CE/FCC Class A
- CE-LVD



## **Knowing Your FTA1170**

**Front Panel** 



#### 1 LAN LED Indicators

Indicate the system power and link status of the system.

2 RJ45 Console Port Connect to RJ45 console devices.

3 Management LAN Port Used for managing the system.

4 USB 3.0 Port Connect to USB 3.0/2.0/1.1 devices.

#### 5 2.5G RJ45 PoE+

Connect the system to a local area network. (PoE is not supported by the FTA1170A).

#### 3 10GBASE-T RJ45 PoE+

Connect the system to a local area network. (PoE is not supported by the FTA1170A).

#### 7 10G SFP+ Switch Ports

Connect SFP+ modules for connecting fiber optic network devices.

#### 8 10G SFP+ NIC Ports

Connect the system to a local area network via SFP+ interface.

#### 9 Nano SIM slot

For plugging a nano SIM card.

#### 10 Power and Reset Button

Power on or turn off the system, or press and hold this button for 4 seconds to restart the system.



## **Rear Panel**





#### 1 LAN Module Slot

LAN module bay to install add-on network modules.

#### 12 AC Power Inlets

Connect the system to an AC power source.



## **CHAPTER 2: JUMPERS AND CONNECTORS**

This chapter describes how to set the jumpers and connectors on the FTA1170 motherboard.

## **Before You Begin**

- Ensure you have a stable, clean working environment. Dust and dirt can get into components and cause a malfunction. Use containers to keep small components separated.
- Adequate lighting and proper tools can prevent you from accidentally damaging the internal components. Most of the procedures that follow require only a few simple tools, including the following:
  - A Philips screwdriver
  - A flat-tipped screwdriver
  - A set of jewelers screwdrivers
  - A grounding strap
  - An anti-static pad
- Using your fingers can disconnect most of the connections. It is recommended that you do not use needle-nosed pliers to disconnect connections as these can damage the soft metal or plastic parts of the connectors.
- Before working on internal components, make sure that the power is off. Ground yourself before touching any internal components, by touching a metal object. Static electricity can damage many of the electronic components. Humid environments tend to have less static electricity than

dry environments. A grounding strap is warranted whenever danger of static electricity exists.

## Precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous.

Follow the guidelines below to avoid damage to your computer or yourself:

- Always disconnect the unit from the power outlet whenever you are working inside the case.
- If possible, wear a grounded wrist strap when you are working inside the computer case. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Don't flex or stress the circuit board.
- Leave all components inside the static-proof packaging that they shipped with until they are ready for installation.
- Use correct screws and do not over tighten screws.



## **Jumper Settings**

A jumper is the simplest kind of electric switch. It consists of two metal pins and a cap. When setting the jumpers, ensure that the jumper caps are placed on the correct pins. When the jumper cap is placed on both pins, the jumper is short. If you remove the jumper cap, or place the jumper cap on just one pin, the jumper is open.

Refer to the illustrations below for examples of what the 2-pin and 3-pin jumpers look like when they are short (on) and open (off).

Two-Pin Jumpers: Open (Left) and Short (Right)



Three-Pin Jumpers: Pins 1 and 2 are Short







## Locations of the Mainbaord Jumpers and Connectors

The following figure shows the mainboard used in the FTA 1170, and indicates the locations of the jumpers and connectors. Refer to this section for detailed pin settings and definitions of the connectors marked in pink on the figure below.

### FTA 1170 Main Board Top View





## Jumpers

1 🗆 0 0 3

## SYS RTC Header Clear

Connector type:  $1 \times 3 = 3 \text{ pin}$ , 2.54mm Connector location: JP6

## **CMOS Header**

Connector type:  $1 \times 3 = 3 \text{ pin}$ , 2.54mm Connector location: JP7

#### 1 🗆 0 0 3

Pin	Function
1-2	Normal (Default)
2-3	Clear CMOS

Pin	Definition
1	N.C.
2	RST_SOC_RTEST_N
3	GND

Pin	Function
1-2	Normal (Default)
2-3	Clear CMOS

Pin	Definition
1	N.C.
2	RST_SRTCRST_N
3	GND



## JTAG SEL Header

Connector type:  $1 \times 2 = 2 \text{ pin}$ , 2.54mm Connector location: JP23

1 🗆 0 2

Pin	Function
Open	Normal (Default)
1-2	Update MB CPLD
	firmware online.

Pin	Definition
1	JTAG_SEL
2	GND



## **Connector Pin Definitions**

## **PSU Power Control Connector**

Connector type: 2 x 5 = 10 pin, 2.0mm Connector location: CN1

Pin	Definition	Pin	Definition
1	SMB_PMBUS_SML1_ STBY_LVC3_SDA	2	SMB-ALERT_A_CAB
3	SMB_PMBUS_SML1_ STBY_LVC3_SCL	4	SMB-ALERT_B_CAB
5	PSON_CAB	6	PRESENT_IN_A_CAB
7	PW_OK_A_CAB	8	PRESENT_IN_B_CAB
9	PW_OK_B_CAB	10	N.C.



## Mini PCle Slot

Connector location: CN2



Pin	Definition	Pin	Definition
1	MPCIE_WAKE# (N.C.)	2	P3V3
3	MINI_COEX1	4	GND
5	MINI_COEX2	6	P1V5
7	WIFI_CLKREQ#	8	N.C.
9	GND	10	N.C.
11	CLK_M2_WIFI2_N	12	N.C.
13	CLK_M2_WIFI2_P	14	N.C.
15	GND	16	N.C.
17	N.C.	18	GND
19	N.C.	20	MPCIE_DIS#
21	GND	22	MPCIE_RST
23	WIFI_RXN_1	24	P3V3
25	WIFI_RXP_1	26	GND

Pin	Definition	Pin	Definition
27	GND	28	P1V5
29	GND	30	MINI_PCIE_CLK
31	WIFI_TXN_1_C	32	MINI_PCIE_DAT
33	WIFI_TXP_1_C	34	GND
35	GND	36	USB2_P2_DN
37	GND	38	USB2_P2_DP
39	P3V3	40	GND
41	P3V3	42	WIFI_LED_WWAN#
43	GND	44	WIFI_LED_WLAN#
45	N.C.	46	WIFI_LED_WPAN#
47	N.C.	48	P1V5
49	N.C.	50	GND
51	N.C.	52	P3V3



## **SATA Connector**

Connector type:  $1 \times 7 = 7$  pin Connector location: CN3, CN4

## **CPLD GPIO Header**

Connector type:  $2 \times 3 = 6 \text{ pin}, 4.2 \text{ mm}$ Connector location: CN5

# <sup>1</sup> 00000 <sup>9</sup> 2 00000 10

7	

CN3		CN4	
Pin	Definition	Pin	Definition
1	GND	1	GND
2	SATA1_TX_DP_C	2	SATA0_TX_DP_C
3	SATA1_TX_DN_C	3	SATA0_TX_DN_C
4	GND	4	GND
5	SATA1_RX_DN_C	5	SATA0_RX_DN_C
6	SATA1_RX_DP_C	6	SATA0_RX_DP_C
7	GND	7	GND

Pin	Definition
1	P12V1
2	P12V1
3	P12V1
4	GND
5	GND
6	GND

#### NE(COM Copyright © 2023 NEXCOM International Co., Ltd. All Rights Reserved.



## **CPLD GPIO Header**

Connector type:  $2 \times 5 = 10 \text{ pin}$ , 2.0mm (4 GPI; 4 GPO) Connector location: CN6

## <sup>1</sup> 00000 <sup>9</sup> 2 00000 10

Pin	Definition	Pin	Definition
1	P3V3_AUX	2	GND
3	CPLD_GPIN1	4	CPLD_GPOUT1
5	CPLD_GPIN2	6	CPLD_GPOUT2
7	CPLD_GPIN3	8	CPLD_GPOUT3
9	CPLD_GPIN4	10	CPLD_GPOUT4



## M.2 2280 Key M PCIe Slot

Connector type: 75 pin Connector location: CN7

Pin	Definition	Pin	Definition
1	GND	13	SSD_TXP_3_C
2	P3V3_SSD	14	P3V3_SSD
3	GND	15	GND
4	P3V3_SSD	16	P3V3_SSD
5	SSD_RXN_3	17	SSD_RXN_2
6	N.C.	18	P3V3_SSD
7	SSD_RXP_3	19	SSD_RXP_2
8	N.C.	20	N.C.
9	GND	21	SSD_CONFIG_0
10	M.2_ACT_LED1	22	N.C.
11	SSD_TXN_3_C	23	SSD_TXN_2_C
12	P3V3_SSD	24	N.C.

Pin	Definition	Pin	Definition
25	SSD_TXP_2_C	36	N.C.
26	N.C.	37	SSD_TXP_1_C
27	GND	38	NGFF_DEVSLP
28	N.C.	39	GND
29	SSD_RXN_1	40	N.C.
30	N.C.	41	SSD_RXP_0
31	SSD_RXP_1	42	N.C.
32	N.C.	43	SSD_RXN_0
33	GND	44	N.C.
34	N.C.	45	GND
35	SSD_TXN_1_C	46	N.C.



Pin	Definition	Pin	Definition
47	SSD_TXN_0_C	58	N.C.
48	N.C.	67	N.C.
49	SSD_TXP_0_C	68	CLK_32K_SUSCLK_SOC
50	SSD_RST_N	69	N.C.
51	GND	70	P3V3_SSD
52	SSD_CLKREQ#	71	GND
53	CLK_M2_SSD_N	72	P3V3_SSD
54	MFG_CLK2	73	GND
55	CLK_M2_SSD_P	74	P3V3_SSD
56	N.C.	75	GND
57	GND		



## Intel XDP Connector (for Debug)

Connector size: BD TO BD 2x 30 = 60 pin 0.5mm Connector location: CN8



Pin	Definition	Pin	Definition
1	P1V05_A	2	JTAG_SOC_TMS
3	JTAG_CPU_TCK	4	JTAG_SOC_TDO
5	JTAG_SOC_TDI	6	RST_LTB_RSTBTN_R_N
7	RST_LTB_PLTRST_R_N	8	PD_JTAG_LTB_TRST
9	JTAG_SOC_TRST_N	10	DBP_DBG_LTB_SOC_PREQ_N
11	DBP_LTB_SOC_PRDY_N	12	P1V05_A
13	TRC_DFX_CLK0_R	14	GND
15	DBP_LTB_PCH_DEBUG_CONSENT_R_N	16	GND
17	FM_LTB_CPU_DEBUG_EN_N	18	N.C.
19	TRC_PTI_DATA_R0	20	N.C.
21	TRC_PTI_DATA_R1	22	N.C.
23	TRC_PTI_DATA_R2	24	N.C.
25	TRC_PTI_DATA_R3	26	N.C.
27	TRC_PTI_DATA_R4	28	N.C.
29	TRC_PTI_DATA_R5	30	N.C.

Pin	Definition	Pin	Definition
31	TRC_PTI_DATA_R6	32	N.C.
33	TRC_PTI_DATA_R7	34	TP_LTB_PIN34
35	TRC_PTI_DATA_R8	36	FM_BOOT_HALT_TIMESYNC2_R
37	TRC_PTI_DATA_R9	38	DBP_LTB_SOC_FBRK_N
39	TRC_PTI_DATA_R10	40	FM_LTB_PWRBTN_R_N
41	TRC_PTI_DATA_R11	42	RST_CPLD_LTB_RSMRST_R_N
43	TRC_PTI_DATA_R12	44	CLK_100M_MIPI60_DN_R
45	TRC_PTI_DATA_R13	46	CLK_100M_MIPI60_DP_R
47	TRC_PTI_DATA_R14	48	SMB_SMT0_LTB_CLK
49	TRC_PTI_DATA_R15	50	SMB_SMT0_LTB_DATA
51	JTAG_PCH_TCK	52	PU_P52_3V3
53	DBP_LTB_MBP1_R_N (N.C.)	54	TP_J5K1_54
55	DBP_LTB_MBPO_R_N (N.C.)	56	TP_J5K1_56
57	GND	58	GND
59	TRC_DFX_CLK1_R	60	PD_LTB_P60

-



## Board to Board Connector (Low Speed)

Connector size: 80 Pin, 0.8mm Connector location: CN10



Pin	Definition	Pin	Definition
1	BMC_CPLD_RI_N	11	BMC_CPLD_DTR_N
2	FM_SOC_CPLD_SLP_S3_N	12	GND
3	BMC_CPLD_RXD	13	BMC_CPLD_TXD
4	N.C.	14	USB2_P0_DN
5	BMC_CPLD_DSR_N	15	BMC_CPLD_RTS_N
6	N.C.	16	USB2_P0_DP
7	BMC_CPLD_CTS_N	17	PU_NIC0_NCSI_RXD_1
8	IRQ_5GM2_WAKE_N	18	GND
9	BMC_CPLD_DCD_N	19	PD_NIC0_NCSI_CRS_DV
10	POWER_OK_EN	20	USB2_P1_DN

Pin	Definition	Pin	Definition
21	NCSI_CLK_I210	31	FM_NIC0_DISABLE_N
22	USB2_P1_DP	32	USB3_TX_N0_C
23	PU_NIC0_NCSI_RXD_0	33	IRQ_NIC0_WAKE_N
24	GND	34	USB3_TX_P0_C
25	PU_NIC0_NCSI_TXD_0	35	RST_CPLD_NIC_RESET_N
26	USB3_RX_N0_C	36	GND
27	PU_NIC0_NCSI_TXD_1	37	SMB_ME_SMT1_ALRT_N
28	USB3_RX_P0_C	38	LED_GBE0_LED0_R
29	PD_NIC0_NCSI_TX_EN	39	GND
30	GND	40	LED_GBE0_LED1_R



Pin	Definition	Pin	Definition
41	SMB_ME_SMT1_CLK	51	LED_GBE1_LED2_R
42	GND	52	P1E_NIC0_RX_DP
43	SMB_ME_SMT1_DATA	53	LED_GBE2_LED0_R
44	CLK_100M_NIC0_DN	54	GND
45	LED_GBE0_LED2_R	55	LED_GBE2_LED1_R
46	CLK_100M_NIC0_DP	56	P1E_NIC0_TX_C_DN
47	LED_GBE1_LED0_R	57	LED_GBE2_LED2_R
48	GND	58	P1E_NIC0_TX_C_DP
49	LED_GBE1_LED1_R	59	LED_GBE3_LED0_R
50	P1E_NIC0_RX_DN	60	GND

Pin	Definition	Pin	Definition
61	LED_GBE3_LED1_R	71	POWER_LED
62	GND	72	P3V3_S
63	LED_GBE3_LED2_R	73	GND
64	P3V3_AUX	74	GND
65	POE_LED	75	P12V2
66	P3V3_AUX	76	P3V3_S
67	WIFI_LED	77	P12V2
68	GND	78	P3V3_S
69	HDD_CPLD_LED	79	GND
70	P3V3_S	80	GND



### **12V Power Connector**

Connector size:  $2 \times 8 = 16 \text{ pin}$  (4.2 mm ATX connector) Connector location: CON1

## **SATA Power Connector**

40000

Connector size:  $1 \times 4 = 4 \text{ pin}$ , 2.54mm Connector location: CON2, CON3



Pin	Definition	Pin	Definition
1	P12V2	9	GND
2	P12V2	10	GND
3	P12V2	11	GND
4	P12V2	12	GND
5	P12V2	13	GND
6	P12V2	14	GND
7	P12V2	15	GND
8	P12V_AUX	16	GND

Pin	Definition	
1	P12V_S2	
2	GND	
3	GND	
4	P5V_S	

## NE(COM

#### Copyright © 2023 NEXCOM International Co., Ltd. All Rights Reserved.



### **Run BMC SO-DIMM Connector**

Connector size: 1 x 260 = 260 Pin Connector location: DIMM1



Pin	Definition	Pin	Definition
1	RSVD for P12V_AUX	18	N.C.
2	N.C.	19	GPIO5_SGPMCK
3	P3V3_AUX	20	N.C.
4	P3V3_AUX	21	CONSOLERX
5	P3V3_AUX	22	N.C.
6	P3V3_AUX	23	CONSOLETX
7	P3V3_AUX	24	GND
8	GND	25	N.C.
9	GND	26	PWM0_GPIO10
10	N.C.	27	PWM2_GPIO9
11	GND	28	PWM1_GPIO12
12	N.C.	29	N.C.
13	GPIO0_SGPMLD	30	N.C.
14	N.C.	31	PWM6_GPIO13
15	GPIO1_SGPMI	32	PWM5_GPIO16
16	N.C.	33	RNBMC_PRSNT#_R
17	GPIO3 SGPMO	34	N.C.

Pin	Definition	Pin	Definition
35	N.C.	52	GND
36	PW_OK_B_CAB	53	BMC_SENSOR_SCL
37	N.C.	54	I2C6SCL_GPIO28
38	GPIO20	55	BMC_SENSOR_SDA
39	GND	56	I2C6SDA_GPIO30
40	GPIO21	57	GND
41	N.C.	58	GND
42	N.C.	59	N.C.
43	N.C.	60	I2C5SCL_GPIO32
44	N.C.	61	N.C.
45	GND	62	I2C5SDA_GPIO34
46	GPIO25	63	N.C.
47	I2C8SCL_GPIO26	64	GND
48	N.C.	65	N.C.
49	I2C8SDA_GPIO27	66	GPIO36
50	I2C13SDA	67	FWSPIMISO_IO1
51	GND	68	GPIO37



Pin	Definition	Pin	Definition
69	N.C.	85	N.C.
70	GPIO38	86	N.C.
71	N.C.	87	EXTRST#
72	N.C.	88	N.C.
73	N.C.	89	GPIO55
74	N.C.	90	TACH6_GPIO56
75	N.C.	91	N.C.
76	N.C.	92	TACH7_GPIO58
77	N.C.	93	N.C.
78	TACH0_GPIO44	94	N.C.
79	N.C.	95	A_VBAT_DETECT
80	TACH1_GPIO46	96	TACH9_GPIO62
81	N.C.	97	N.C.
82	TACH2_GPIO48	98	TACH10_GPIO64
83	WDTRST2_GPIO49	99	N.C.
84	N.C.	100	TACH11_GPIO66

Pin	Definition	Pin	Definition
101	N.C.	117	N.C.
102	TACH12_GPIO68	118	N.C.
103	N.C.	119	N.C.
104	TACH13_GPIO70	120	N.C.
105	IRQ_SMB_PWR_ALERT_N	121	PW_OK_A_CAB
106	TACH14_GPIO72	122	N.C.
107	GPIO73	123	I2C2SCL_GPI085
108	N.C.	124	N.C.
109	N.C.	125	I2C2SDA_GPI087
110	GND	126	GND
111	P1V05_A	127	GND
112	PECI	128	I2C1SCL_GPIO88
113	N.C.	129	N.C.
114	GND	130	I2C1SDA_GPIO90
115	N.C.	131	N.C.
116	N.C.	132	GND



Pin	Definition	Pin	Definition
133	GND	149	PERXP
134	I2C4SCL_GPIO92	150	GPIO103_UART4TX
135	N.C.	151	GND
136	I2C4SDA_GPIO94	152	P3V3_AUX
137	N.C.	153	PCIE_RX_BMC_DN
138	N.C.	154	N.C.
139	GND	155	PCIE_RX_BMC_DP
140	N.C.	156	N.C.
141	I2C12SCL_GPIO98	157	GND
142	PERSTN	158	N.C.
143	I2C12SDA_GPIO99	159	PEREFCLKN
144	N.C.	160	N.C.
145	GND	161	PEREFCLKP
146	N.C.	162	N.C.
147	PERXN	163	GND
148	GPIO102_UART4RX	164	JTAG1TDO

Pin	Definition	Pin	Definition
165	LPCRST#_ESPIRST#	181	BMC_RSVD1
166	JTAG1TDI	182	P3V3_ADC4
167	ESPI_IO3_LPC_AD1	183	BMC_RSVD2
168	N.C.	184	P1V05_A_ADC5
169	ESPI_IO3_LPC_AD0	185	GND
170	JTAG1TCK	186	PVCCIN_ADC6
171	LPCIRQ#_ESPIALERT#	187	I2C10SCL_GPIO110
172	JTAG1TMS	188	PVNN_NAC_ADC7
173	H_LPC_FRAME_N	189	N.C.
174	P12V2_ADC0	190	SYSCS#_GPIO112
175	ESPI_IO3_LPC_AD3	191	GND
176	P3V3_AUX_ADC1	192	SPI_PCH_IBMC_DI
177	ESPI_IO3_LPC_AD2	193	N.C.
178	P5V_AUX_ADC2	194	SPI_PCH_IBMC_DO
179	LPCCLK_ESPICLK	195	N.C.
180	P3V3_SOC_ADC3	196	SPI_PCH_IBMC_CLK



Pin	Definition	Pin	Definition
197	GND	213	N.C.
198	SPI1CS0#_GPI0116	214	N.C.
199	I2C11SCL_GPIO117	215	GND
200	SPI_IBMC_SSB_DO	216	RMIICRSDV
201	I2C11SDA_GPIO118	217	USB2_P3_DN
202	SPI_SSB_IBMC_DI	218	N.C.
203	GND	219	USB2_P3_DP
204	N.C.	220	NICO_NCSI_CLK_IN_R
205	I2C3SCL_GPIO119	221	GND
206	N.C.	222	GND
207	I2C3SDA_GPI0121	223	N.C.
208	SPI_IBMC_SSB_CLK	224	RMIITXEN
209	N.C.	225	N.C.
210	SPI1CS1#_GPIO124	226	GND
211	N.C.	227	GND
212	GND	228	RMIIRXD0

Pin	Definition	Pin	Definition
229	N.C.	245	GND
230	RMIIRXD1	246	N.C.
231	N.C.	247	N.C.
232	GND	248	N.C.
233	GND	249	N.C.
234	PU_NIC0_NCSI_TXD_0	250	N.C.
235	N.C.	251	GND
236	PU_NIC0_NCSI_TXD_1	252	PVNN_PCH_ADC8
237	N.C.	253	BMC_RESET#
238	GND	254	P1V2_VDDQ_ADC9
239	GND	255	P3V_RTC_ADC13
240	N.C.	256	P5V_ADC10
241	N.C.	257	P1V05_NAC_ADC11
242	N.C.	258	P1V8_A_ADC12
243	N.C.	259	N.C.
244	N.C.	260	N.C.


#### **FAN Wafer Connector**

Connector size:  $1 \times 6 = 6$  Pin, 1.25mm Connector location: J2, J3, J4



Pin	Definition	
1	GND	
2	P12V_S1	
3	SYS_FAN1_TACH_R	
4	SYS_FAN1_PWM_R	
5	GND	
6	P12V_S1	

-



### PCIe Gen3 x16 Riser Card Board to Board Connector

Connector size: 2 x 75 = 150 Pin, 0.8mm Connector location: J5



Pin	Definition	Pin	Definition
1	GND	16	PE_SOC_TX_C_DN1
2	GND	17	PE_SOC_RX_DN1
3	IRQ_PCIE_WAKE_N	18	PE_SOC_TX_C_DP1
4	SMB_PCIE_S1_CLK_R	19	GND
5	PCIE_SLOT_RST_N	20	GND
6	SMB_PCIE_S1_DATA_R	21	PE_SOC_RX_DP2
7	GND	22	PE_SOC_TX_C_DN2
8	GND	23	PE_SOC_RX_DN2
9	PE_SOC_RX_DP0	24	PE_SOC_TX_C_DP2
10	PE_SOC_TX_C_DN0	25	GND
11	PE_SOC_RX_DN0	26	GND
12	PE_SOC_TX_C_DP0	27	PE_SOC_RX_DP3
13	GND	28	PE_SOC_TX_C_DN3
14	GND	29	PE_SOC_RX_DN3
15	PE_SOC_RX_DP1	30	PE_SOC_TX_C_DP3

Pin	Definition	Pin	Definition
31	GND	46	PE_SOC_TX_C_DP6
32	GND	47	PE_SOC_RX_DN6
33	PE_SOC_RX_DP4	48	PE_SOC_TX_C_DN6
34	PE_SOC_TX_C_DN4	49	GND
35	PE_SOC_RX_DN4	50	GND
36	PE_SOC_TX_C_DP4	51	PE_SOC_RX_DP7
37	GND	52	PE_SOC_TX_C_DP7
38	GND	53	PE_SOC_RX_DN7
39	PE_SOC_RX_DP5	54	PE_SOC_TX_C_DN7
40	PE_SOC_TX_C_DP5	55	GND
41	PE_SOC_RX_DN5	56	GND
42	PE_SOC_TX_C_DN5	57	PE_SOC_RX_DP8
43	GND	58	PE_SOC_TX_C_DP8
44	GND	59	PE_SOC_RX_DN8
45	PE_SOC_RX_DP6	60	PE_SOC_TX_C_DN8



Pin	Definition	Pin	Definition
61	GND	76	PE_SOC_TX_C_DP11
62	GND	77	PE_SOC_RX_DN11
63	PE_SOC_RX_DP9	78	PE_SOC_TX_C_DN11
64	PE_SOC_TX_C_DP9	79	GND
65	PE_SOC_RX_DN9	80	GND
66	PE_SOC_TX_C_DN9	81	PE_SOC_RX_DP12
67	GND	82	PE_SOC_TX_C_DP12
68	GND	83	PE_SOC_RX_DN12
69	PE_SOC_RX_DP10	84	PE_SOC_TX_C_DN12
70	PE_SOC_TX_C_DP10	85	GND
71	PE_SOC_RX_DN10	86	GND
72	PE_SOC_TX_C_DN10	87	PE_SOC_RX_DP13
73	GND	88	PE_SOC_TX_C_DP13
74	GND	89	PE_SOC_RX_DN13
75	PE_SOC_RX_DP11	90	PE_SOC_TX_C_DN13

Pin	Definition	Pin	Definition
91	GND	106	DISCONN_A0_EN
92	GND	107	CLK_PCIE_SLOT_N
93	PE_SOC_RX_DP14	108	DISCONN_A1_EN
94	PE_SOC_TX_C_DP14	109	GND
95	PE_SOC_RX_DN14	110	GND
96	PE_SOC_TX_C_DN14	111	DISCONN_A2_EN
97	GND	112	P3V3_S
98	GND	113	DISCONN_A3_EN
99	PE_SOC_RX_DP15	114	P3V3_S
100	PE_SOC_TX_C_DP15	115	GND
101	PE_SOC_RX_DN15	116	GND
102	PE_SOC_TX_C_DN15	117	BYPASS_SLOT_EN
103	GND	118	P3V3_S
104	GND	119	BYPASS_SLOT_A
105	CLK_PCIE_SLOT_P	120	P3V3_S



Pin	Definition	Pin	Definition
121	GND	136	P12V_S2
122	GND	137	N.C.
123	BYPASS_SLOT_B	138	P12V_S2
124	P3V3_AUX	139	N.C.
125	BYPASS_SLOT_C	140	GND
126	P3V3_AUX	141	N.C.
127	GND	142	P12V_S2
128	GND	143	N.C.
129	BYPASS_SLOT_D	144	P12V_S2
130	P12V_S2	145	N.C.
131	N.C.	146	GND
132	P12V_S2	147	N.C.
133	N.C.	148	N.C.
134	GND	149	N.C.
135	N.C.	150	N.C.



## **Board to Board Connector (High Speed)**

Connector size: 150 Pin, 0.8mm Connector location: J6

1 2		00000000000000000000000000000000000000	°0 O	149 150
--------	--	--	---------	------------

Pin	Definition	Pin	Definition
1	GND	16	USB_0_OC#
2	GND	17	SMB_HOST_DATA
3	P12V2	18	CLK_32K_SUSCLK_SOC
4	P3V3_S	19	GND
5	P12V2	20	GND
6	P3V3_S	21	SW_INIT_DONE
7	GND	22	SW_UART_RXD
8	GND	23	TEMP_INT_N
9	P12V2	24	SW_UART_TXD
10	P12V_AUX	25	GND
11	P12V2	26	GND
12	P12V_AUX	27	3258_MR_N
13	GND	28	PMD_L0_RX_P
14	GND	29	RESETN1
15	SMB_HOST_CLK	30	PMD_L0_RX_N

Pin	Definition	Pin	Definition
31	GND	46	PMD_L3_RX_P
32	GND	47	CR0_TX_DN1
33	SYSRST_OUT_N	48	PMD_L3_RX_N
34	PMD_L1_RX_P	49	GND
35	RST_M_RESET_N	50	GND
36	PMD_L1_RX_N	51	CR0_TX_DP2
37	GND	52	3258_L0_RX_P_C
38	GND	53	CR0_TX_DN2
39	CR0_TX_DP0	54	3258_L0_RX_N_C
40	PMD_L2_RX_P	55	GND
41	CR0_TX_DN0	56	GND
42	PMD_L2_RX_N	57	CR0_TX_DP3
43	GND	58	3258_L1_RX_P_C
44	GND	59	CR0_TX_DN3
45	CR0_TX_DP1	60	3258_L1_RX_N_C



Pin	Definition	Pin	Definition
61	GND	76	5G_LTE_TX_DP0_C
62	GND	77	3258_L2_TX_N
63	3258_L0_TX_P	78	5G_LTE_TX_DN0_C
64	3258_L2_RX_P_C	79	GND
65	3258_L0_TX_N	80	GND
66	3258_L2_RX_N_C	81	3258_L3_TX_P
67	GND	82	5G_LTE_TX_DP1_C
68	GND	83	3258_L3_TX_N
69	3258_L1_TX_P	84	5G_LTE_TX_DN1_C
70	3258_L3_RX_P_C	85	GND
71	3258_L1_TX_N	86	GND
72	3258_L3_RX_N_C	87	CLK_OUT_DP6
73	GND	88	5G_LTE_TX_DP2_C
74	GND	89	CLK_OUT_DN6
75	3258_L2_TX_P	90	5G_LTE_TX_DN2_C

Pin	Definition	Pin	Definition
91	GND	106	5G_LTE_RX_DP1
92	GND	107	SMB_GBE1_I2C_DATA_R
93	CLK_OUT_DP7	108	5G_LTE_RX_DN1
94	USB3_TX_P1_C	109	GND
95	CLK_OUT_DN7	110	GND
96	USB3_TX_N1_C	111	SMB_GBE2_I2C_CLK_R
97	GND	112	5G_LTE_RX_DP2
98	GND	113	SMB_GBE2_I2C_DATA_R
99	SMB_GBE0_I2C_CLK_R	114	5G_LTE_RX_DN2
100	5G_LTE_RX_DP0_C	115	GND
101	SMB_GBE0_I2C_DATA_R	116	GND
102	5G_LTE_RX_DN0_C	117	SMB_GBE3_I2C_CLK_R
103	GND	118	USB3_RX_P1_C
104	GND	119	SMB_GBE3_I2C_DATA_R
105	SMB_GBE1_I2C_CLK_R	120	USB3_RX_N1_C



Pin	Definition	Pin	Definition
121	GND	136	SMB_ETH_MNG_I2C_CLK_R
122	GND	137	PD_GBE_GPIO5_R
123	SMB_CPLD_I2C_CLK_R	138	SMB_ETH_MNG_I2C_DATA_R
124	PEX_SW_RX_P	139	GND
125	SMB_CPLD_I2C_DATA_R	140	GND
126	PEX_SW_RX_N	141	FM_GBE_GPIO2_PRSNT_3_ N_R
127	GND	142	RST_SW_LTB_RSTBTN_N
128	GND	143	RST_GBE_GPIO3_RST_1_N_R
129	RST_GBE_GPIO6_RST_0_N_R	144	FM_SW_LTB_PWRBTN_N
130	PEX_SW_TX_P_C	145	GND
131	FM_GBE_GPIO7_INT_0_N_R	146	GND
132	PEX_SW_TX_N_C	147	RST_GBE_GPIO0_RST_3_N_R
133	GND	148	CLK_100M_SW_DP
134	GND	149	FM_GBE_GPIO1_INT_3_N_R
135	FM_GBE_GPIO4_INT_1_N_R	150	CLK_100M_SW_DN



#### **Core Power PWM SMBus Header**

Connector size: 1 x 3 = 3 pin, 2.54mm Connector location: JP21\*

#### NAC Power PWM SMBus Header

Connector size:  $1 \times 3 = 3 \text{ pin}$ , 2.54mm Connector location: JP22\*

1	0	0	3

Pin	Definition		
1	PVCCIN_SCL		
2	PVCCIN_SDA		
3	GND		

Pin	Definition
1	PVNN_NAC_SCL
2	PVNN_NAC_SDA
3	GND

10003



These headers are designed to update VCCIN, PVNN\_PCH PM ICs using a tool.



#### **CPLD JTAG Header**

1 00000 6

Connector size:  $1 \times 6 = 6 \text{ pin}$ , 2.54mm Connector location: JP26

### LPC TPM Module Header

Connector size: 2 x 7 = 14 pin, 2.0mm Connector location: JP34

## <sup>13</sup> 00000001 14 00000002

Pin	Definition		
1	P3V3_AUX		
2	GND		
3	JTAG_PLD_TCK		
4	JTAG_PLD_TDO		
5	JTAG_PLD_TDI		
6	JTAG_PLD_TMS		

Pin	Definition	Pin	Definition
1	GND	2	CLK_LPC_TPM
3	-	4	H_LPC_FRAME_N
5	ESPI_IO3_LPC_AD2	6	RST_TPM_N
7	ESPI_IO3_LPC_AD1	8	ESPI_IO3_LPC_AD3
9	GND	10	ESPI_IO3_LPC_AD0
11	INT_SERIRQ	12	P3V3_SOC
13	GND	14	GND



#### **CPLD JTAG Header**

Connector size: 1 x 4 = 4 pin, 2.54mm Connector location: JP35

1 🗆 0 0 0 4

Pin	Definition
1	P3V3_AUX
2	BMC_CPLD_DEBUG_RXD
5	BMC_CPLD_DEBUG_TXD
6	GND



## Locations of the Extension Board Connectors

The following figures show the extension board used in the FTA 1170, and indicates the locations of the connectors. Refer to this section for detailed pin settings and definitions of the connectors marked in pink on the figure below.

#### FTA 1170 Extension Board Top View





## **Connector Pin Definitions**

### PoE Power Connector (only 54V supply)

Connector type: 2 x 10 = 20 Pin, 1.25mm Connector location: CN2, CN5, CN6, CN13



CN2 (For Ma	arvell 2.	5GBE	Phy1)
-------------	-----------	------	-------

Pin	Definition	Pin	Definition
1	N.C.	11	POE2_ADDR0
2	N.C.	12	N.C.
3	N.C.	13	POE2_ADDR1
4	N.C.	14	N.C.
5	N.C.	15	POE2_ADDR2
6	N.C.	16	N.C.
7	N.C.	17	N.C.
8	N.C.	18	N.C.
9	V_3P3V_POE_MOD2	19	GND_POE2
10	V_3P3V_POE_MOD2	20	N.C.

#### CN5 (For Marvell 2.5GBE Phy2)

Pin	Definition	Pin	Definition
1	N.C.	11	POE3_ADDR0
2	N.C.	12	N.C.
3	N.C.	13	POE3_ADDR1
4	N.C.	14	N.C.
5	N.C.	15	POE3_ADDR2
6	N.C.	16	N.C.
7	N.C.	17	N.C.
8	N.C.	18	N.C.
9	V_3P3V_POE_MOD3	19	GND_POE3
10	V_3P3V_POE_MOD3	20	N.C.

## NECOM

#### CN6 (For Marvell 2.5GBE Phy3)

Pin	Definition	Pin	Definition
1	N.C.	11	POE1_ADDR0
2	N.C.	12	N.C.
3	N.C.	13	POE1_ADDR1
4	N.C.	14	N.C.
5	N.C.	15	POE1_ADDR2
6	N.C.	16	N.C.
7	N.C.	17	N.C.
8	N.C.	18	N.C.
9	V_3P3V_POE_MOD1	19	GND_POE1
10	V_3P3V_POE_MOD1	20	N.C.

#### CN13 (For X557 10GBE)

Pin	Definition	Pin	Definition
1	N.C.	11	POE4_ADDR0
2	N.C.	12	N.C.
3	N.C.	13	POE4_ADDR1
4	N.C.	14	N.C.
5	N.C.	15	POE4_ADDR2
6	N.C.	16	N.C.
7	N.C.	17	N.C.
8	N.C.	18	N.C.
9	V_3P3V_POE_MOD4	19	GND_POE4
10	V_3P3V_POE_MOD4	20	N.C.



## Board to Board Connector (Low Speed)

Connector type: 80 Pin, 0.8mm Connector location: CN9



Pin	Definition	Pin	Definition
1	BMC_CPLD_RI_N	11	BMC_CPLD_DTR_N
2	FM_SOC_CPLD_SLP_S3_N	12	GND
3	BMC_CPLD_RXD	13	BMC_CPLD_TXD
4	N.C.	14	USB2_P0_DN
5	BMC_CPLD_DSR_N	15	BMC_CPLD_RTS_N
6	N.C.	16	USB2_P0_DP
7	BMC_CPLD_CTS_N	17	PU_NIC0_NCSI_RXD_1
8	IRQ_5GM2_WAKE_N	18	GND
9	BMC_CPLD_DCD_N	19	PD_NIC0_NCSI_CRS_DV
10	MB_ATX_PWROK	20	USB2_P1_DN

Pin	Definition	Pin	Definition
21	NICO_NCSI_CLK_IN_R	31	FM_NIC0_DISABLE_N
22	USB2_P1_DP	32	USB3_TX_N0
23	PU_NIC0_NCSI_RXD_0	33	IRQ_NIC0_WAKE
24	GND	34	USB3_TX_P0
25	PU_NIC0_NCSI_TXD_0	35	RST_CPLD_NIC1_RESET_ N_R
26	USB3_RX_N0	36	GND
27	PU_NIC0_NCSI_TXD_1	37	SMB_NICO_ALERT_N
28	USB3_RX_PO	38	LED_GBE0_LED0
29	PD_NIC0_NCSI_TX_EN	39	GND
30	GND	40	LED_GBE0_LED1



Pin	Definition	Pin	Definition
41	SMB_NIC0_CLK	51	LED_GBE1_LED2
42	GND	52	P1E_NIC0_RX_DP
43	SMB_NIC0_DAT	53	LED_GBE2_LED0
44	CLK_100M_NIC0_DN_R	54	GND
45	LED_GBE0_LED2	55	LED_GBE2_LED1
46	CLK_100M_NIC0_DP_R	56	P1E_NIC0_TX_C_DN
47	LED_GBE1_LED0	57	LED_GBE2_LED2
48	GND	58	P1E_NIC0_TX_C_DP
49	LED_GBE1_LED1	59	LED_GBE3_LED0
50	P1E_NIC0_RX_DN	60	GND

Pin	Definition	Pin	Definition
61	LED_GBE3_LED1	71	POWER_LED
62	GND	72	P3V3_MB
63	LED_GBE3_LED2	73	GND
64	P3V3_AUX	74	GND
65	POE_LED	75	P12V
66	P3V3_AUX	76	P3V3_MB
67	WIFI_LED	77	P12V
68	GND	78	P3V3_MB
69	HDD_CPLD_LED	79	GND
70	P3V3_MB	80	GND



## **Board to Board Connector (High Speed)**

Connector size: 150 Pin, 0.8mm Connector location: CN11

149	°	0	]	1
150	0	0	⊲	2

Pin	Definition	Pin	Definition
1	GND	16	USB_0_OC#
2	GND	17	SMB_HOST_DATA
3	P12V	18	CLK_32K_SUSCLK_SOC
4	P3V3_MB	19	GND
5	P12V	20	GND
6	P3V3_MB	21	SW_INIT_DONE_R
7	GND	22	SW_UART_RXD
8	GND	23	TEMP_INT_N_R
9	P12V	24	SW_UART_TXD
10	P12V_AUX	25	GND
11	P12V	26	GND
12	P12V_AUX	27	3258_MR_N
13	GND	28	PMD_L0_RX_P
14	GND	29	RESETN1_R
15	SMB_HOST_CLK	30	PMD_L0_RX_N

Pin	Definition	Pin	Definition
31	GND	46	PMD_L3_RX_P
32	GND	47	PMD_L1_TX_N
33	SYSRST_OUT_N_R	48	PMD_L3_RX_N
34	PMD_L1_RX_P	49	GND
35	RST_M_RESET_N_R	50	GND
36	PMD_L1_RX_N	51	PMD_L2_TX_P
37	GND	52	3258_L0_RX_P
38	GND	53	PMD_L2_TX_N
39	PMD_L0_TX_P	54	3258_L0_RX_N
40	PMD_L2_RX_P	55	GND
41	PMD_L0_TX_N	56	GND
42	PMD_L2_RX_N	57	PMD_L3_TX_P
43	GND	58	3258_L1_RX_P
44	GND	59	PMD_L3_TX_N
45	PMD_L1_TX_P	60	3258_L1_RX_N



Pin	Definition	Pin	Definition
61	GND	76	N.C.
62	GND	77	88X3310P_L0_TX_N
63	3258_L0_TX_P	78	N.C.
64	88X3310P_L0_RX_P	79	GND
65	3258_L0_TX_N	80	GND
66	88X3310P_L0_RX_N	81	88X3310P_L1_TX_P
67	GND	82	5G_LTE_TX_DP1
68	GND	83	88X3310P_L1_TX_N
69	3258_L1_TX_P	84	5G_LTE_TX_DN1
70	88X3310P_L1_RX_P	85	GND
71	3258_L1_TX_N	86	GND
72	88X3310P_L1_RX_N	87	CLK_OUT_DP6
73	GND	88	5G_LTE_TX_DP2
74	GND	89	CLK_OUT_DN6
75	88X3310P_L0_TX_P	90	5G_LTE_TX_DN2

Pin	Definition	Pin	Definition
91	GND	106	5G_LTE_RX_DP1
92	GND	107	TP_SMB_GBE1_I2C_DATA
93	CLK_OUT_DP7	108	5G_LTE_RX_DN1
94	USB3_TX_P1	109	GND
95	CLK_OUT_DN7	110	GND
96	USB3_TX_N1	111	TP_SMB_GBE2_I2C_CLK
97	GND	112	5G_LTE_RX_DP2
98	GND	113	TP_SMB_GBE2_I2C_DATA
99	SMB_GBE0_I2C_CLK	114	5G_LTE_RX_DN2
100	N.C.	115	GND
101	SMB_GBE0_I2C_DATA	116	GND
102	N.C.	117	TP_SMB_GBE3_I2C_CLK
103	GND	118	USB3_RX_P1
104	GND	119	TP_SMB_GBE3_I2C_DATA
105	TP_SMB_GBE1_I2C_CLK	120	USB3_RX_N1



Pin	Definition	Pin	Definition
121	GND	136	X557_MDC_SCL
122	GND	137	PD_GBE_GPIO5_R
123	SMB_CPLD_I2C_CLK_R	138	X557_MDIO_SDA
124	PEX_SW_RX_P_C	139	GND
125	SMB_CPLD_I2C_DATA_R	140	GND
126	PEX_SW_RX_N_C	141	FM_GBE_GPIO2_ PRSNT_3_ N_R
127	GND	142	RST_SW_LTB_RSTBTN_N
128	GND	143	RST_GBE_GPIO3_RST_1_ N_R
129	RST_GBE_GPIO6_RST_0_ N_R	144	FM_SW_LTB_PWRBTN_N
130	PEX_SW_TX_P	145	GND
131	FM_GBE_GPIO7_INT_0_N_ R	146	GND
132	PEX_SW_TX_N	147	RST_GBE_GPIO0_RST_3_ N_R
133	GND	148	CLK_100M_SW_DP_R
134	GND	149	FM_GBE_GPIO1_INT_3_N_ R
135	FM_GBE_GPIO4_INT_1_N_ R	150	CLK_100M_SW_DN_R



#### **Reset Button Header**

Connector size:  $1 \times 2 = 2$  Pin, 2.0mm Connector location: CN14

#### **Power Button Header**

Connector size:  $1 \times 2 = 2$  Pin, 2.54mm Connector location: JP1



Pin	Definition	
1	FP_RST_BTN_N_R	
2	GND	

1	0	0	2
		_	

Pin	Definition	
1	PWRBTN#_C	
2	GND	



#### PoE Box Header (Connector to PoE module)

Connector type: 2 x 20 = 40 Pin, 1.27mm Connector location: JP2, JP5, JP6, JP79

# 

#### JP2 (for Marvell 2.5GBE RJ45 P1~P8 PoE)

Pin	Definition	Pin	Definition
1	N.C.	11	N.C.
2	VPORT_NEG_OUT4	12	N.C.
3	N.C.	13	P12V
4	N.C.	14	VPORT_NEG_OUT1
5	N.C.	15	GND
6 VPORT_NEG_OUT3 16 V_52V_O		V_52V_OUT	
7	N.C.	17	P3V3
8	N.C.	18	V_52V_OUT
9	N.C.	19	P3V3
10	VPORT_NEG_OUT2	20	V_52V_OUT

Pin	Definition	Pin	Definition
21	GND	31	DRG_SPI_MOSI
22 V_52V_OUT 32 VPORT_		VPORT_NEG_OUT7	
23	23 POE1_DETECT 33 GND		GND
24 V_52V_OUT 34 N.C.		N.C.	
25	GND	35	DRG_SPI_SCK
26 V_52V_OUT 36 VPORT_NEG_0		VPORT_NEG_OUT6	
27	DRG_SPI_MISO	37	GND
28	VPORT_NEG_OUT8	38	N.C.
29	GND	39	DRG_SPI_CS
30	N.C.	40	VPORT_NEG_OUT5



#### JP5 (for Marvell 2.5GBE RJ45 P9~P16 PoE)

Pin	Definition	Pin	Definition
1	N.C.	11	N.C.
2	VPORT_NEG_OUT12	12	N.C.
3 N.C. 13 P12V		P12V	
4	4 N.C. 14 VPORT_NEG_		VPORT_NEG_OUT9
5	N.C.	15	GND
6	6 VPORT_NEG_OUT11 16 V_52V_O		V_52V_OUT
7	N.C.	N.C. 17 P3V3	
8	N.C. 18 V_52V_OUT		V_52V_OUT
9	N.C.	19	P3V3
10	VPORT_NEG_OUT10	20	V_52V_OUT

Pin	Definition	Pin	Definition	
21	GND	31	DRG_SPI_MOSI	
22	V_52V_OUT	32	VPORT_NEG_OUT15	
23	23 POE2_DETECT 33 GND		GND	
24 V_52V_OUT 34 N.C.		N.C.		
25	GND	35	DRG_SPI_SCK	
26 V_52V_OUT 36 VPORT_NEG_C		VPORT_NEG_OUT14		
27	DRG_SPI_MISO	_SPI_MISO 37 GND		
28	VPORT_NEG_OUT16	38	N.C.	
29	GND	39	DRG_SPI_CS	
30	N.C.	40	40 VPORT_NEG_OUT13	



#### JP6 (for Marvell 2.5GBE RJ45 P17~P24 PoE)

Pin	Definition	Pin	Definition
1	N.C.	11	N.C.
2	VPORT_NEG_OUT20	12	N.C.
3 N.C. 13 P12V		P12V	
4 N.C. 14 VPORT_NEG_		VPORT_NEG_OUT17	
5	N.C.	15	GND
6 VPORT_NEG_OUT19 16 V_52V_0		V_52V_OUT	
7 N.C. 17 P3V3		P3V3	
8	N.C. 18 V_52V_OUT		V_52V_OUT
9	N.C.	19 P3V3	
10	VPORT_NEG_OUT18	20	V_52V_OUT

Pin	Definition	Pin	Definition	
21 GND 31 DRG_SP		DRG_SPI_MOSI		
22	V_52V_OUT	32	VPORT_NEG_OUT23	
23	POE3_DETECT	33	GND	
24	24 V_52V_OUT 34 N.C.		N.C.	
25	GND	35	DRG_SPI_SCK	
26 V_52V_OUT 36 VPORT_NEG_C		VPORT_NEG_OUT22		
27	DRG_SPI_MISO	37	GND	
28	VPORT_NEG_OUT24	38	N.C.	
29	GND	39	DRG_SPI_CS	
30	N.C.	40	VPORT_NEG_OUT21	



#### JP79 (for Intel X557 10GBE RJ45 P1~P4 PoE)

Pin	Definition	Pin	Definition
1	N.C.	11	N.C.
2	VPORT_NEG_10G_OUT4	12	N.C.
3	N.C.	13	P12V
4	4 N.C.		VPORT_NEG_10G_OUT1
5 N.C. 15 GND		GND	
6	6 VPORT_NEG_10G_OUT3		V_52V_OUT
7	N.C.	17	P3V3
8	N.C.	18	V_52V_OUT
9	N.C.	19	P3V3
10	VPORT_NEG_10G_OUT2	20	V_52V_OUT

Pin	Definition	Pin	Definition	
21 GND 31 DRG_SPI_M		DRG_SPI_MOSI		
22	V_52V_OUT	32	VPORT_NEG_10G_OUT7	
23	POE4_DETECT	33	GND	
24	V_52V_OUT	34	N.C.	
25	GND	35	DRG_SPI_SCK	
26	V_52V_OUT	36	VPORT_NEG_10G_OUT6	
27	DRG_SPI_MISO	37	GND	
28	VPORT_NEG_10G_OUT8	38	N.C.	
29	GND	39	DRG_SPI_CS	
30	N.C. 40 VPORT_NEG_10G_OU		VPORT_NEG_10G_OUT5	



#### I/O Board CPLD JTAG Header

Connector size:  $1 \times 6 = 6 \text{ Pin}$ , 2.54mm Connector location: JP12

#### 10000006

Pin	Definition	
1	P3V3_AUX	
2	GND	
3	JTAG_CPLD_TCK	
4	JTAG_CPLD_TDO	
5	JTAG_CPLD_TDI	
6	JTAG_CPLD_TMS	



This header is designed to update CPLD firmware with a diamond programmer.



# Block Diagram





#### FTA1170A

-





## CHAPTER 3: SYSTEM SETUP

## **Removing the Chassis Cover**



Prior to removing the chassis cover, make sure the unit's power is off and disconnected from the power sources for 20 seconds to prevent electric shock or system damage.

- 1. The screws located on the rear panel and used to secure the cover to the chassis. Remove these screws and put them in a safe place for later use.
- 2. With the screws removed, gently slide the cover outwards and then lift up the cover to remove it.





## **Installing Memory Modules**

Before beginning the memory installation, please pay attention to the following notices.

- Before installing or removing internal components on the motherboard, please ensure that the AC power cord is unplugged for at least over 20 seconds.
- The memory modules are foolproof design and can only be installed in one direction. If you encounter difficulty, try reversing the module's orientation and avoid using force to prevent damage.
- It is recommended to install memory modules with the same brand, speed, and capacity.
- To install a single memory module, it is recommended to plug the module into the A1 slot. For dual-channel installation, the sequence should be A1 and B1, followed by A0 and B0. Refer to Chapter 2 for the mechanical location and sequence of DIMM slots.

1. Locate the DIMM slots on the motherboard and release the locks.



2. Insert the modules into the sockets at a 90 degree angle. Apply firm, even pressure to both ends of the modules until they slip into the sockets.





## Installing an M.2 Key M Storage Device

1. Locate the M.2 slot on the motherboard.



2. Insert the M.2 SSD into the M.2 slot at a 45 degree angle until the gold -plated connector on the edge of the module completely disappears inside the slot.





3. With the module fully inserted, tighten a screw into the mounting hole on the module to secure it.





## Installing a BMC Module

1. Locate the BMC socket on the motherboard.



2. Insert the BMC module into the BMC socket at a 45 degree angle until the gold-plated connector on the edge of the module completely disappears inside the slot.



-



3. Push the module down until the clips on both sides of the socket lock into position. A distinctive "click" sound will indicate the module is correctly locked into place.





## Installing a 2.5" SATA Hard Drive

1. Locate the HDD bracket, then unscrew and remove it from the chassis.



2. Tighten the hard drive with screws on both sides of the bracket. The bracket is designed to support the assembly of up to 2 hard drives.





3. Tighten the bracket with the installed hard drive(s) in the location from which it was previously removed on the chassis.



4. Connect the SATA data and power cables from the hard drive(s) to the motherboard.





CON2 CON3 CN4 CN3



## CHAPTER 4: BIOS SETUP

This chapter describes how to use the BIOS setup program for the FTA 1170 series. The BIOS screens provided in this chapter are for reference only and may change if the BIOS is updated in the future.

To check for the latest updates and revisions, visit the NEXCOM website at www.nexcom.com.tw.

## **About BIOS Setup**

The BIOS (Basic Input and Output System) Setup program is a menu driven utility that enables you to make changes to the system configuration and tailor your system to suit your individual work needs. It is a ROM-based configuration utility that displays the system's configuration status and provides you with a tool to set system parameters.

These parameters are stored in non-volatile battery-backed-up CMOS RAM that saves this information even when the power is turned off. When the system is turned back on, the system is configured with the values found in CMOS.

With easy-to-use pull down menus, you can configure items such as:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

COM:

The settings made in the setup program affect how the computer performs. It is important, therefore, first to try to understand all the setup options, and second, to make settings appropriate for the way you use the computer.

## When to Configure the BIOS

- This program should be executed under the following conditions:
- When changing the system configuration
- When a configuration error is detected by the system and you are prompted to make changes to the setup program
- When resetting the system clock
- When redefining the communication ports to prevent any conflicts
- When making changes to the Power Management configuration
- When changing the password or making other changes to the security setup

Normally, CMOS setup is needed when the system hardware is not consistent with the information contained in the CMOS RAM, whenever the CMOS RAM has lost power, or the system features need to be changed.



## **Default Configuration**

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

## **Entering Setup**

When the system is powered on, the BIOS will enter the Power-On Self Test (POST) routines. These routines perform various diagnostic checks; if an error is encountered, the error will be reported in one of two different ways:

- If the error occurs before the display device is initialized, a series of beeps will be transmitted.
- If the error occurs after the display device is initialized, the screen will display the error message.

Powering on the computer and immediately pressing  $\int_{Del}$  allows you to enter Setup.

## Legends

Кеу	Function
← →	Moves the highlight left or right to select a menu.
	Moves the highlight up or down between sub-menu or fields.
Esc	Exits the BIOS Setup Utility.
+	Scrolls forward through the values or options of the highlighted field.
-	Scrolls backward through the values or options of the highlighted field.
Tab ≝	Selects a field.
F1	Displays General Help.
F2	Load previous values.
F3	Load optimized default values.
F4	Saves and exits the Setup program.
Enter,	Press <enter> to enter the highlighted sub-menu</enter>

NEXCOM
# NEXCOM

## Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.

## Submenu

When " $\blacktriangleright$ " appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press  $\blacksquare$ .



# **BIOS Setup Utility**

Once you enter the AMI BIOS Setup Utility, the Main Menu will appear on the screen. The main menu allows you to select from several setup functions and one exit. Use arrow keys to select among the items and press **to** accept or enter the submenu.

## Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.

Aptio Setup – Main Advanced Platfor	American Megatrends Interna m Configuration Socket Com	ational, LLC. ∩figurationServer Mgmt ►
BIOS Information		Set the Date. Use Tab
BIOS Vendor	American Megatrends	to switch between Date
Core Version	5.19	elements.
Compliancy	UEFI 2.7; PI 1.6	Default Ranges:
Project Version	G170- 0.04 ×64	Year: 1998-9999
Build Date and Time	06/05/2023 08:55:19	Months: 1–12
Current BIOS	BIOS1	Days: Dependent on month
		Range of Years may vary.
Memory Information		
lotal Memory	65536 MB	Mar Calast Canasa
	[Pot 04/05/2008]	the Select Streen
System Date	[541 01/05/2006]	Fotor: Select
agatem Time	[01:00:04]	+/-: Change Ont
		F1: General Help
		F2: Previous Values
		F3: Optimized Defaults
		F4: Save & Reset
		ESC: Exit
Ver 2 21 1277 Conuright	(C) 2023 American Megatre	nds International IIC

#### System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Monday to Sunday. Month displays the month, from 1 to 12. Date displays the date, from 1 to 31. Year displays the year, from 2005 to 2099.

#### System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.



## **Advanced**

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.



Setting incorrect field values may cause the system to malfunction.

<ul> <li>Trusted Computing</li> <li>IT8786 Super IO Configuration</li> <li>UEFI Variables Protection</li> <li>Serial Port Console Redirection</li> <li>PCI Subsystem Settings</li> <li>USB Configuration</li> <li>Network Stack Configuration</li> <li>NWWE Configuration</li> </ul>	Trusted Computing Settings
▶ SUIU Configuration	++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit

## **Trusted Computing**

This section is used to configure Trusted Platform Module (TPM) settings.

Configuration		Enables or Disables
Security Device		BIOS support for
		security device. O.S.
Disable Block Sid	[Disabled]	will not show Security
NO Security Device		Device. TCG EFI
Found		protocol and INT1A
		interface will not be
		available.
		++: Select Screen
		T4: Select Item
		Enter: Select
		+/-: Change Upt.
		F1: General Help
		F2: Previous values
		F3: Uptimized Defaults
		F4: Save & Reset

## **Security Device Support**

Enable or disable BIOS support for security device. O.S will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

## **Disable Block Sid**

Override to allow SID authentication in TCG storage device.



## **IT8786 Super IO Configuration**

This section is used to configure the serial port of the super IO.



## Super IO Chip

Display the super I/O chip used on the board.

## **Serial Port 1 Configuration**

Enter Serial Port 1 Configuration submenu.

## Serial Port 1 Configuration

This section is used to configure serial port 1.

Serial Port 1 Config	uration	Enable or Disable
Serial Port	[Enabled]	Serial Point (COM)
Device Settings	IO=3F8h; IRQ=4;	
Change Settings	[Auto]	
		↔+: Select Screen
		↑↓: Select Item
		Enter: Select
		+/-: Change Upt.
		F1: General Help
		F3: Ontimized Default
		F4: Save & Reset
		ECC. Evit

## Serial Port

Enable or disable the serial port.

## **Change Settings**

Select an optimal setting for the Super IO device.



## **UEFI Variables Protection**

Aptio Setup - Advanced	American Megatrends In	ternational, LLC.
Password protection of Runtime Variables	[Enable]	Control the NVRAM Runtime Variable protection through System Admin Password
		<pre>++: Select Screen f↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save &amp; Reset ESC: Exit</pre>
Ver. 2.21.1277 Copyrigh	t (C) 2023 American Meg	atrends International, LLC.

## **Password Protection of Runtime Variables**

Control the NVRAM runtime variable protection through system admin password.

## Serial Port Console Redirection

This section is used to configure the serial port that will be used for console redirection.

СЛМО	Console Redirection
Console Redirection [Enabled]	
Console Redirection Settings	
	++: Select Screen
	↑↓: Select Item
	Enter: Select
	+/-: Change Opt.
	F1: General Help
	E3: Ontimized Defaults
	F4: Save & Reset
	ESC: Exit

## **Console Redirection**

Enable or disable the console redirection.

## **Console Redirection Settings**

When Console Redirection is enabled, Console Redirection Settings will be available.



#### **Console Redirection Settings**

This section is used to configure serial port 1.



## **Terminal Type**

- ANSI Extended ASCII character set.
- VT100 ASCII character set.
- VT100+ Extends VT100 to support color, function keys, etc.
- VT-UTF8 Uses UTF8 encoding to map Unicode characters onto 1 or more bytes.

#### **Bits Per Second**

Selects the serial port transmission speed. The speed must match the other side. Long or noisy lines may require a lower speed.

## Data Bits

The options are 7 and 8.

## Parity

A parity bit can be sent with the data bits to detect some transmission errors.

Even Parity bit is 0 if the number of 1's in the data bits is even.

Odd Parity bit is 0 if number of 1's in the data bits is odd.

#### **Stop Bits**

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.

## **Flow Control**

Flow control can prevent data loss from buffer overflow. When sending data and the receiving buffers are full, a "stop" signal can be sent to stop the data flow.

## **VT-UTF8 Combo Key Support**

Enable or disable the VT-UTF8 combo key support.

## **Recorder Mode**

When this field is enabled, only text will be sent. This is to capture the terminal data.

## **Resolution 100x31**

Enable or disable the extended terminal resolution.

## Putty Keypad

Selects the Putty keyboard emulation type.



## **PCI Subsystem Settings**

This section is used to configure the PCI.



## Above 4G Decoding

Enable or disable the decoding of 64-bit devices in 4G address space.

## **SR-IOV Support**

Enable or disable the SR-IOV support.



## **USB** Configuration

This section is used to configure the USB.

Aptio Setup – Advanced	American Megatrends Intern	ational, LLC.
USB Configuration	<b>_</b>	Enables Legacy USB
USB Module Version	25	disables legacy support
USB Controllers:		connected. DISABLE
USB Devices:		devices available only
1 Drive, 1 Keyboar	d	for EFI applications.
	[Enabled]	
XHCI Hand-off	[Enabled]	→+: Select Screen
USB Mass Storage	[Enabled]	†∔: Select Item
Driver Support		Enter: Select
		+/-: Change Opt.
USB hardware delays		F1: General Help
and time-outs:		F2: Previous Values
USB transfer time-out	[20 sec]	F3: Optimized Defaults
Device reset time—out	[20 sec] 🔹 🔻	F4: Save & Reset
		ESC: Exit
Ver. 2.21.1277 Copyright	(C) 2023 American Megatre	nds International, LLC.

## Legacy USB Support

Enable Enable Legacy USB.

Auto Disable support for Legacy when no USB devices are connected. Disable Keep USB devices available only for EFI applications.

## **XHCI Hand-off**

This is a workaround for OSes that does not support XHCI hand-off. The XHCI ownership change should be claimed by the XHCI driver.

## **USB Mass Storage Driver Support**

Enable or disable the USB mass storage driver support.

## **USB Transfer Time-out**

The time-out value for control, bulk, and Interrupt transfers.

## **Device Reset Time-out**

Select the USB mass storage device's start unit command timeout.

#### **Device Power-up Delay**

Maximum time the value will take before it properly reports itself to the Host Controller. "Auto" uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

## **Mass Storage Devices**

Configure the mass storage device emulation type. AUTO enumerates devices according to their media format. Optical drives are emulated as CDROM, drives with no media will be emulated according to a drive type.



## **Network Stack Configuration**

This section is used to configure the network stack.



#### **Network Stack**

Enable or disable the UEFI network stack. Once enabled, more options are available for configuration.

#### **Ipv4 PXE Support**

Enable or disable IPv4 PXE support. If disabled, the IPv4 boot option will not be created.

#### Ipv4 HTTP Support

Enable or disable Ipv4 HTTP support.

## **Ipv6 PXE Support**

Enable or disable IPv6 PXE support. If disabled, the IPv6 boot option will not be created.

## Ipv6 HTTP Support

Enable or disable Ipv6 HTTP support.

## PXE boot wait time

Configure the wait time to press the ESC key to abort the PXE boot.

#### Media detect count

Configure the number of times the media will be checked.



## **NVMe Configuration**

This section is used to configure the NVMe devices installed.



#### **NVMe Device**

Display the model of installed NVMe device. Press **Enter** for more advanced configurations.

## **NVMe Device Configuration**

This section is used to configure the installed NVMe device.

Aptio Setup - Advanced	American Megatrends Inter	national, LLC.
Seg:Bus:Dev:Func Model Number Total Size Vendor ID Device ID	00:01:00:00 TS128GMTE652T 128.0 GB 126F 2263	Select either Short or Extended Self Test. Short option will take couple of minutes and extended option will take several minutes to
Namespace: 1 Device Self Test: Self Test Option	Size: 128.0 GB [Short]	complete.
Self Test Action Run Device Self Test	[Controller Only Test]	<pre>++: Select Screen 1↓: Select Item Enter: Select</pre>
Short Device Selftest Result	[Not Available]	+/−: Change Opt. F1: General Help
Extended Device Selftest Result	[Not Available]	F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Ver. 2.21.1277 Copyrigh	t (C) 2023 American Megatr	ends International, LLC.

## Self Test Option

Configure the method used for self test.

Short: Short option will take couple of minutes to complete. Extended: Extended option will take several minutes to complete.

## Self Test Action

Configure the items used for self test. Controller Only Test and Controller and NameSpace Test options are available. Selecting Controller and NameSpace Test will take longer to complete.

## **Run Device Self Test**

Run the device self test according to the self test option and action selected. Pressing the **Esc** key will abort the test.



## **SDIO Configuration**

This section is used to configure the SDIO access mode.



#### **SDIO Access Mode**

Auto option: Access SD device in DMA mode if controller supports it, otherwise in PIO mode.

DMA option: Access SD device in DMA mode. PIO option: Access SD device in PIO mode.

·

## eMMC Device

Mass storage device emulation type. "Auto" enumerates devices less than 530MB as floppies. Forced FDD option can be used to force HDD formatted drive to boot as FDD.



## **Platform Configuration**

PCH-IO Configuration     PCH Parameters     Setup Warning:     Setting items on this Screen to incorrect	gmt 🕨
values may cause system to malfunction! ++: Select Screen 11: Select Item	
Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Default F4: Save & Reset ESC: Exit	ts

## **PCH Configuration**

Enter the PCH Configuration submenu.

## **PCH-IO Configuration**

Aptio Setup – American Megatrends Intern Platform Configuration	ational, LLC.
PCH-IO Configuration PCI Express Configuration Fia Mux Configuration SATA Configuration USB Configuration SCS Configuration Show Power Type Status AT	PCI Express Configuration settings ++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Ver. 2.21.1277 Copyright (C) 2023 American Megatre	nds International, LLC.

# PCI Express Configuration / Fia Mux Configuration / SATA Configuration / USB Configuration / SCS Configuration

Press Enter to access each submenu.



## **PCI Express Configuration**

Aptio Setup – American Megatrends Interna Platform Configuration	ational, LLC.
PCI Express Configuration	PCI Express Root Port Settings.
<ul> <li>PCI Express Root Port 1</li> <li>PCI Express Root Port 3</li> <li>PCI Express Root Port 4</li> <li>PCI Express Root Port 9</li> <li>PCI Express Root Port 10</li> <li>PCI Express Root Port 11</li> <li>PCI Express Root Port 12</li> </ul>	
▶ PUI Express Root Port 12	<pre>++: Select Screen  \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$</pre>
Ver. 2.21.1277 Copyright (C) 2023 American Megatrer	nds International, LLC.

## PCI Express Root Port 1~12

Press **Enter** to access each submenu and configure each option.

'-----



## PCI Express Configuration > PCI Express Root Port

PCI Express Root Port       [Enabled]         ASPM       [Disabled]         L1 Substates       [Disabled]         PCIe Speed       [Auto]         CTO       [default (50us - 50ms)]         ++: Select Screen       11: Select Item         Enter: Select       +/-: Change Opt.         F2: Previous Values       F2: Previous Values	Aptio Setup – Platfo	American Megatrends In rm Configuration	ternational, LLC.
++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values	PCI Express Root Port 1 ASPM L1 Substates PCIe Speed CTO	[Enabled] [Disabled] [Disabled] [Auto] [default (50us - 50ms)]	Control the PCI Express Root Port.
F3: Optimized Defau F4: Save & Reset ESC: Exit			++: Select Screen 1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit

## PCIe Speed

Configure the speed of the PCI Express port.

## СТ0

Configure the CT0 for PCI Express.

## **PCI Express Root Port**

Enable or disable the PCI Express port.

## **ASPM Support**

Select the ASPM level.

Force L0	Forces all links to LO state.
Auto	The BIOS automatically selects an ASPM level.
Disable	Disables ASPM

## L1 Substates

Configure the L1 Substates settings.

-



## **FIA Mux Configuration**

Aptio Setup – American Megatrends International, LLC. Platform Configuration			
FIA Mux Configuration Override FIA Mux Configuration	[Disabled] [O: Valid]	▲ By Ena overn: config	abling this you ide the platform guration on FIA/WM
Invalidate Lane O	[Lane Override Disabled]		
Read config:	Lane O PCIE owner [SATA: N/A][RP: enabled, with 1x])		
Lane 1	[Lane Override Disabled]		elect Screen
Read config:	Lane 1 PCIE owner [SATA: N/A][RP: not enabled])	†∔: Se Enter: +/-: (	elect Item : Select Change Opt.
Lane 2	[Lane Override Disabled]	F1: Ge F2: Pr F3: Op F4: Sa ESC: E	eneral Help revious Values otimized Defaults ave & Reset Exit
Ver. 2.21.1277 Copyrigh	t (C) 2023 American Me	atrends Int	ternational, LLC.

## **FIA Mux Configuration**

By enabling this you override the platform configuration on FIA/WM.

## **SATA Configuration**

SATA Controller 3
Device Options Setting
++: Select Screen
T4: Select Item
+/-: Change Ont.
F1: General Help
F2: Previous Values
F3: Optimized Defaults
F4: Save & Reset
ESU: EXIL

## **Controller 3 SATA Configuration**

Enter the Controller 3 SATA Configuration submenu.

36



## SATA Configuration > Controller 3 SATA Configuration

Aptio Setup – Platfor	American Megatrends Interr m Configuration	national, LLC.
Controller 3 SATA Config	uration	SATA test settings
SATA Configuration SATA Test Mode ▶ Software Feature Mask Co Controller 3	[Enabled] [Disabled] nfiguration for	
Aggressive LPM Support SATA Port 1 (CN4)	[Enabled] ST500LM030-2E7 - 500.1	
Software Preserve Port 1 Hot Plug Configured as eSATA External Spin Up Device SATA Device Type SATA Port 1 DevSlp	GB Unknown [Enabled] [Disabled] Hot Plug supported [Disabled] [Hard Disk Drive] [Disabled]	<pre>++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save &amp; Reset ESC: Exit</pre>
Ver. 2.21.1277 Copyright	(C) 2023 American Megatre	ends International, LLC.

## **SATA Configuration**

Enable or disable SATA configuration.

## SATA Test Mode

Enable or disable SATA test mode.

## Software Feature Mask Configuration for Controller 3

Enable or disable software feature mask configuration for controller 3.

## Aggressive LPM Support

Enable or disable aggressive LPM support.

## Port 1/3

Enable or disable SATA port 1/3.

## Hot Plug

Enable or disable hot plugging feature on SATA port 1/3.

#### **External** Enable or disable the feature of External

## **Spin Up Device** Enable or disable staggered spin up on devices connected to SATA port 1/3.

#### SATA Device Type

Identiy what type of SATA device is connected.

## SATA Port 1/3 DevSlp

Enable or disable SATA Port 1/3 DevSlp. Before enabling DevSlp, board rework is needed.

## **DITO Configuration**

Enable or disable DITO configuration.



## **USB** Configuration

Aptio Setup – American Megatrends International, LLC. Platform Configuration		
USB Configuration		Selectively Enable/Disable the
USB Port Disable Override		corresponding USB port from reporting a Device Connection to the controller.
		↔: Select Screen 11: Select Item Enter: Select
		+/–: Change Opt. F1: General Help
		F2: Previous Values F3: Optimized Defaults F4: Save & Reset
Von 2 21 1277 Conunit	abt (C) 2022 Amonicon	ESC: Exit
ver. 2.21.1277 Copyri;	gni (c) 2023 American	megatrenus international, LLC.

## **USB Port Disable Override**

Selectively enable or disable the corresponding USB port from reporting a device connection to the controller.

## **SCS** Configuration

eMMC 5.1 Controller eMMC 5.1 HS400 Mode	[Enabled] [Enabled]	Enable or Disable SUS eMMC 5.1 Controller
		<pre>++: Select Screen f↓: Select Item Enter: Select +/-: Change Opt.</pre>
		F1: General Help F2: Previous Values F3: Optimized Default F4: Save & Reset ESC: Exit

## eMMC 5.1 Controller

Enable or disable SCS eMMC 5.1 controller.

## eMMC 5.1 HS400 Mode

Enable or disable eMMC 5.1 HS400 mode.

-



## **Socket Configuration**

Aptio Setup – American Megatrends International, LLC. Main Advanced Platform Configuration Socket Configuration Server Mgmt I		
<ul> <li>Processor Configuration</li> <li>Memory Configuration</li> <li>IIO Configuration</li> <li>Advanced Power Management Configuration</li> </ul>	Displays and provides option to change the Processor Settings	
	<pre>++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save &amp; Reset ESC: Exit</pre>	
Ver. 2.21.1277 Copyright (C) 2023 American Megatr	ends International, LLC.	

# Processor Configuration / Memory Configuration / IIO Configuration / Advanced Power Management Configuration

Press **Enter** to access each submenu.



## **Processor Configuration**

Aptio Setup -	American Megatrends Intern Socket Co	ational, LLC. nfiguration
Processor Configuration		Change Per-Socket Settings
Per-Socket Configuration Processor BSP Revision Processor Socket Processor ID Processor Frequency Processor Max Ratio Processor Min Ratio Microcode Revision L1 Cache RAM(Per Core) L2 Cache RAM(Per Package) L3 Cache RAM(Per Package) Processor O Version	80667 - SNR CO Socket O 00080667* 2.2006Hz 16H 08H 4C000021 64KB 9216KB 7680KB Intel Atom(R) P5322 pro cessor	++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Ver. 2.21.1277 Copyright	(C) 2023 American Megatre	nds International, LLC.

## **Pre-Socker Configuration**

Change pre-socket settings.

## Max CPUID Value Limit

Set this field to Disable when using Windows XP. Set this field to Enable when using legacy operating systems so that the system will boot even when it doesn't support CPUs with extended CPUID function.

## Hardware Prefetcher

Enable or disable the MLC streamer prefetcher.

#### Adjacent Cache Prefetch

Enable or disable the adjacent cache prefetch.

#### Extended APIC

Enable or disable extended APIC support.

#### VMX

When this field is set to Enabled, the VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

## Enable SMX

Enable or disable Secure Mode Extensions.



## **Memory Configuration**

	Maximum Memory
 Integrated Memory Controller (iMC)  Memory Frequency [Auto] ▶ Memory Topology	<ul> <li>Frequency Selections in Mhz. If Enforce POR is disabled, user will be able to run at higher frequencies than the memory support (limited by processor support).</li> </ul>
	++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit

## **Memory Frequency**

Configure the maximum frequency of the memory. Do not select Reserved.

## Memory Topology

Press Enter to see the information on the memory installed.

## **IIO Configuration**

IIO Configuration  SocketO Configuration Fintel VT for Directed I/O (VT-d) ++: Select S 14: Select 1 Enter: Select +/-: Change F1: General F2: Previous F3: Optimize F4: Save & F ESC: Exit	Screen Item ct Opt. Help s Values ed Defaults Reset

## Socket0 Configuration

Enter the Socket0 Configuration submenu.

## Intel VT for Directed I/O (VT-d)

Enter the Intel VT for Directed I/O (VT-d) submenu.



## Socket0 Configuration

	Aptio Setup –	American Megatrends Interna Socket Com	ational, LLC. nfiguration
IOUO (IIO ▶ Port 1A	PCIe Port 1)	[Auto]	Selects PCIe port Bifurcation for selected slot(s) ++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Ver. 2.21	.1277 Copyright	(C) 2023 American Megatre	nds International, LLC.

## IOU0 (II0 PCIe Port 1)

Select PCIe port bifurcation for selected slot(s).

## Port 1A

Enter the Port 1A submenu.



## Socket0 Configuration > Port 1 A

Aptio Setup –	American Megatrends Inte Socket	rnational, LLC. Configuration
Port 1A  PCI-E Port Link Speed Override Max Link Width PCI-E Port Link Status PCI-E Port Link Speed PCI-E Port Link Speed PCI-E Port MPSS PCI-E ASPM Support	[Yes] [Auto] [Auto] Link Did Not Train Max Width x16 Link Did Not Train [Auto] [Disable]	In auto mode the BIDS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Enable/Disable is used **: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit
Ver. 2.21.1277 Copyright	t (C) 2023 American Megat	rends International, LLC.

## PCI-E Port

Enable or disable the PCIe port. In auto mode the BIOS will remove the EXP port if there is no device or errors on that device and the device is not HP capable. Disable is used to disable the port and hide its CFG space

## Link Speed

Configure the link speed for the PCIe port.

## **Override Max Link Width**

Configure the link speed to override the max link width set by bifurcation.

## PCI-E Port MPSS

Configure the PCI-e Port MPSS.

## PCI-E ASPM Support

This option enables or disables the ASPM support for all downstream devices.



## **Advanced Power Management Configuration**

Aptio Setup – American Megatrends International, LLC. Socket Configuration		
Advanced Power Management Configuration 	P State Control Configuration Sub Menu, include Turbo, XE and etc.	
	++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit	
Ver. 2.21.1277 Copyright (C) 2023 American Megatrends International, LLC.		

## **CPU P State Control**

Enter the CPU P State Control submenu.

## **CPU C State Control**

Enter the CPU C State Control submenu.

## **CPU P State Control**

CPU P State Control		Enable/Disable EIST
SpeedStep (Pstates) EIST PSD Function Energy Efficient Turbo	(Disable) [HW_ALL] [Disable]	() -States)
		++: Select Screen †1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset FSC: Fxit

## SpeedStep (Pstates)

Enable or disable EIST (P-States).

## **Energy Efficient Turbo**

Enable or disable Energy Efficient Turbo.



## **CPU C State Control**

Aptio Setup – American Megatrends International, LLC. Socket Configuration		
CPU C State Control		Allows Monitor and MWAIT instructions.
Enable Monitor MWAIT CPU C1 auto demotion CPU C1 auto undemotion CPU C6 report Enhanced Halt State (C1E) OS ACPI Cx	[Disable] [Disable] [Disable] [Disable] [Disable] [ACPI C2]	
		<pre>+: Select Screen  14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save &amp; Reset ESC: Exit</pre>
Ver. 2.21.1277 Copyright (C) 2023 American Megatrends International, LLC.		

## **Enable Monitor MWAIT**

Enable or disable monitoring and MWAIT instructions.

## **CPU C1** auto demotion

Enable or disable CPU C1 auto demotion.

#### CPU C1 auto undemotion

Enable or disable CPU C1 auto undemotion.

## CPU C6 report

Enable or disable C6 report to the operating system.

## Enhanced Halt State (C1E)

Enable or disable Enhanced Halt State (C1E) for lower power consumption.

## OS ACPI Cx

Enable or disable C3 report or C6 report to OS ACPI C2 or ACPI C3.



## Security

Aptio Setup – American Megatrends International, LLC. <mark>∢ Security</mark> Boot Save & Exit		
Password Description If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup. The password length must be in the following range:	Set Administrator Password	
Minimum length 3 Maximum length 20 Administrator Password	++: Select Screen 11: Select Item	
HDD Security Configuration: TS1286MTE652T P1:ST500LM030-2E717D P3:ST500LM030-2E717D	Filer: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Reset ESC: Exit	
Ver. 2.21.1277 Copyright (C) 2023 American Megatre	ends International, LLC.	

## Administrator Password

Set the administrator's password for the system.



## Boot



## **Setup Prompt Timeout**

Select the number of seconds to wait for the setup activation key. 65535(0xFFFF) denotes indefinite waiting.

#### **Bootup NumLock State**

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.

## **Quiet Boot**

Enable or disable the quiet boot function.

#### Fast Boot

Enable or disable boot with initialization of a minimal set of devices required to launch active boot option. This doesn't affect the BBS boot options.

#### Boot Option #1 ~ #X

Select the boot sequence of the hard drives. X represents the quantity of connected devices.

#### **UEFI Hard Disk Drive BBS Priorities**

Configure the boot device priority sequence from available UEFI hard disk drives.

## **UEFI USB Key Drive BBS Priorities**

Configure the boot device priority sequence from available UEFI USB key drives.



## Save & Exit

Aptio Setup – American Megatrends International, LLC. ◀ Security Boot Save & Exit		
Save Options Save Changes and Reset Discard Changes and Reset Default Options Restore Defaults Boot Override UEFI OS (JetFlashTranscend 8GB 8.07)	Reset the system after saving the changes.	
ubuntu (P1: ST500LM030-2E717D) UEFI: Built-in EFI Shell Launch EFI Shell from filesystem device	<pre>++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save &amp; Reset ESC: Exit</pre>	
Ver. 2.21.1277 Copyright (C) 2023 American Megatrends International, LLC.		

#### Save Changes and Reset

To save the changes and reset, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

## **Discard Changes and Exit**

To exit the Setup utility without saving the changes, select this field then press <Enter>. You may be prompted to confirm again before exiting. You can also press <ESC> to exit without saving the changes.

## **Restore Defaults**

To restore the BIOS to default settings, select this field then press <Enter>. A dialog box will appear. Confirm by selecting Yes.

## **Boot Override**

To bypass the boot sequence from the Boot Option List and boot from a particular device, select the desired device and press <Enter>.