Drivers Installation Guide

| Driver Pack	RaptorLake-S_20231220
Model	NViS66162/NViS5704
Installation Sequence	1. Chipset 2. GNA 3. CSME 4. Graphics 5. Serial IO 6. HID Event Filter 7. Audio 8. LAN

1. Chipset

### *1.1 Enter 1.Chipset-10.1.19199.8340-Public-MUP folder*


1.2 Execute SetupChipset.exe

1.3 Restart Windows to apply driver changes

2. GNA

## *2.1 Enter 2.gna-03.00.00.1457-win-3_0_sv2_resign-20220819 folder*


2.2 Right-Click on gna.inf and Install

# 3. CSME

3.1 Enter 3.CSME-16.1.25.2124-SW folder


3.2 Execute SetupME.exe

3.3 Restart Windows to apply driver changes

4. Graphics

## 4.1 Enter 4.Intel Graphics Driver Production Version 101.4146 folder


4.2 Execute Installer.exe

5. Serial IO

5.1 Enter 5.SerialIO_30.100.2221.20v2_RPL_ADL-PCH_22H2 folder


5.2 Execute SetupSerialIO.exe

5.3 Restart Windows to apply driver changes

6. HID Event Filter

6.1 Enter 6.HIDEventFilterDriver-2.2.2.1_v3_RS5_19H1_20H1_21H2_22H2_Certified folder


## *6.2 Right-Click on HidEventFilter.inf and Install*

7. Audio

7.1 Enter 7.Audio > 1_Intel_ISST-10.29.00.7919-ADL > Drivers folder


## *7.2 Right-Click on IntcAudioBus.inf and Install*

7.3 Right-Click on IntcOED.inf and Install

## *7.4 Enter 7.Audio > 2.9066_FF00_PG476_Win10_RS4_RS5_19H1_20H1_Win7_WHQL folder*

7.5 Execute Setup.exe

7.6 Restart Windows to apply driver changes

8. LAN

8.1 Enter 8.LAN_driver > Release_28.2.1 folder

8.2 Execute Autorun.exe

8.3 Restart Windows to apply driver changes